

# TDRV018-SW-82

## Linux Device Driver

Reconfigurable FPGA

Version 1.3.x

## User Manual

Issue 1.3.0

April 2024

## TDRV018-SW-82

Linux Device Driver

Reconfigurable FPGA

Supported Modules:

TPMC634  
TXMC633  
TXMC635  
TXMC637  
TXMC638  
TXMC639  
TPCE636

This document contains information, which is proprietary to TEWS Technologies GmbH. Any reproduction without written permission is forbidden.

TEWS Technologies GmbH has made any effort to ensure that this manual is accurate and complete. However TEWS Technologies GmbH reserves the right to change the product described in this document at any time without notice.

TEWS Technologies GmbH is not liable for any damage arising out of the application or use of the device described herein.

©2015-2024 by TEWS Technologies GmbH

Issue	Description	Date
1.0.0	First Issue	September 10, 2015
1.0.1	Typos in examples corrected	August 29, 2017
1.1.0	Support for new hardware added, API extended	October 12, 2017
1.2.0	Support for new hardware added	December 16, 2021
1.3.0	Support for new hardware added New address TEWS Technologies GmbH	April 4, 2024

# Table of Contents

<b>1</b>	<b>INTRODUCTION.....</b>	<b>5</b>
<b>2</b>	<b>INSTALLATION.....</b>	<b>6</b>
<b>2.1</b>	<b>Build and Install the Device Driver.....</b>	<b>6</b>
<b>2.2</b>	<b>Uninstall the Device Driver .....</b>	<b>7</b>
<b>2.3</b>	<b>Install Device Driver into the running Kernel.....</b>	<b>7</b>
<b>2.4</b>	<b>Remove Device Driver from the running Kernel.....</b>	<b>7</b>
<b>2.5</b>	<b>Change Major Device Number .....</b>	<b>8</b>
<b>3</b>	<b>API DOCUMENTATION .....</b>	<b>9</b>
<b>3.1</b>	<b>General Functions.....</b>	<b>9</b>
<b>3.1.1</b>	<b>tdrv018Open .....</b>	<b>9</b>
<b>3.1.2</b>	<b>tdrv018Close.....</b>	<b>11</b>
<b>3.1.3</b>	<b>tdrv018GetPciInfo .....</b>	<b>13</b>
<b>3.1.4</b>	<b>tdrv018GetBoardInfo.....</b>	<b>15</b>
<b>3.1.5</b>	<b>tdrv018GetBoardName .....</b>	<b>17</b>
<b>3.1.6</b>	<b>tdrv018GetBoardSerial .....</b>	<b>19</b>
<b>3.1.7</b>	<b>tdrv018GetBoardFWVersion.....</b>	<b>21</b>
<b>3.1.8</b>	<b>tdrv018GetFpgaStatus.....</b>	<b>23</b>
<b>3.2</b>	<b>Local Bus Control Functions.....</b>	<b>25</b>
<b>3.2.1</b>	<b>tdrv018LocalBusControl.....</b>	<b>25</b>
<b>3.2.2</b>	<b>tdrv018LocalBusStatus .....</b>	<b>27</b>
<b>3.3</b>	<b>EEPROM Access Functions.....</b>	<b>29</b>
<b>3.3.1</b>	<b>tdrv018EepromWrite .....</b>	<b>29</b>
<b>3.3.2</b>	<b>tdrv018EepromRead.....</b>	<b>31</b>
<b>3.4</b>	<b>Pull-Resistor Configuration Functions.....</b>	<b>33</b>
<b>3.4.1</b>	<b>tdrv018PullConfigSet .....</b>	<b>33</b>
<b>3.4.2</b>	<b>tdrv018PullConfigGet.....</b>	<b>35</b>
<b>3.5</b>	<b>FPGA Programming Functions .....</b>	<b>37</b>
<b>3.5.1</b>	<b>tdrv018ProgSpiFlashFromFile .....</b>	<b>37</b>
<b>3.5.2</b>	<b>tdrv018ProgSpiFlash .....</b>	<b>39</b>
<b>3.5.3</b>	<b>tdrv018ProgFpgaFromFile .....</b>	<b>41</b>
<b>3.5.4</b>	<b>tdrv018ProgFpga .....</b>	<b>43</b>
<b>3.5.5</b>	<b>tdrv018ConfigFromSpiFlash .....</b>	<b>45</b>
<b>3.5.6</b>	<b>tdrv018PcieLinkEnable .....</b>	<b>47</b>
<b>3.5.7</b>	<b>tdrv018PcieLinkDisable .....</b>	<b>49</b>
<b>3.5.8</b>	<b>tdrv018RestorePciHeader.....</b>	<b>51</b>
<b>3.6</b>	<b>Register Access Functions.....</b>	<b>53</b>
<b>3.6.1</b>	<b>tdrv018Read8 .....</b>	<b>53</b>
<b>3.6.2</b>	<b>tdrv018ReadBE16.....</b>	<b>56</b>
<b>3.6.3</b>	<b>tdrv018ReadLE16 .....</b>	<b>59</b>
<b>3.6.4</b>	<b>tdrv018ReadBE32.....</b>	<b>62</b>
<b>3.6.5</b>	<b>tdrv018ReadLE32 .....</b>	<b>65</b>
<b>3.6.6</b>	<b>tdrv018Write8.....</b>	<b>68</b>
<b>3.6.7</b>	<b>tdrv018WriteBE16.....</b>	<b>71</b>
<b>3.6.8</b>	<b>tdrv018WriteLE16 .....</b>	<b>74</b>
<b>3.6.9</b>	<b>tdrv018WriteBE32 .....</b>	<b>77</b>
<b>3.6.10</b>	<b>tdrv018WriteLE32 .....</b>	<b>80</b>
<b>3.7</b>	<b>Resource Mapping Functions.....</b>	<b>83</b>
<b>3.7.1</b>	<b>tdrv018PciResourceMap.....</b>	<b>83</b>
<b>3.7.2</b>	<b>tdrv018PciResourceUnmap .....</b>	<b>86</b>

---

<b>3.8 Interrupt Functions .....</b>	<b>88</b>
3.8.1    tdrv018lInterruptWait .....	88
3.8.2    tdrv018lInterruptRegisterCallbackThread .....	91
3.8.3    tdrv018lInterruptUnregisterCallback .....	98
3.8.4    tdrv018lInterruptConfig .....	100
<b>4 DIAGNOSTIC.....</b>	<b>105</b>

# 1 Introduction

The TDRV018-SW-82 Linux device driver allows the operation of the TDRV018 compatible devices conforming to the Linux I/O system specification.

The TDRV018-SW-82 device driver supports the following features:

- Program onboard SPI Flash, initiate FPGA reconfiguration
- Program onboard FPGA directly
- Read/write FPGA registers (32bit / 16bit / 8bit)
- Read/write specific PCI Configuration EEPROM registers
- Wait for interrupts
- Register Callback functions for interrupt handling
- Driver functions (except for SPI/FPGA programming) are thread-safe, as long as unique handles are used.

The TDRV018-SW-82 supports the modules listed below:

TPMC634	Reconfigurable FPGA	PMC
TXMC633	Reconfigurable FPGA with 64 TTL I/O / 32 Differential I/O Lines	XMC
TXMC635	Reconfigurable FPGA with 48 x TTL IO / 32 x 16 Bit Analog In / 8 x 16 Bit Analog Out	XMC
TXMC637	Reconfigurable FPGA with 16 x 16 bit Analog Input 8 x 16 bit Analog Output and 32 digital I/O	XMC
TXMC638	Reconfigurable FPGA with 24 x 16 Bit Analog Input	XMC
TXMC639	Reconfigurable FPGA with 16 x 16 bit Analog Input 8 x 16 bit Analog Output and 32 digital I/O	XMC
TPCE636	Reconfigurable FPGA with 16 x 16 bit Analog Input and 16 x 16 bit Analog Output	PCIe

**In this document all supported modules and devices will be called TDRV018. Specials for a certain device will be advised.**

To get more information about the features and use of supported devices it is recommended to read the manuals listed below.

TPMC634 (or compatible) User Manual
TXMC633 (or compatible) User Manual
TXMC635 (or compatible) User Manual
TXMC637 (or compatible) User Manual
TXMC638 (or compatible) User Manual
TXMC639 (or compatible) User Manual
TPCE636 (or compatible) User Manual

## 2 Installation

The directory TDRV018-SW-82 on the distribution media contains the following files:

TDRV018-SW-82-1.3.0.pdf	This manual in PDF format
TDRV018-SW-82-SRC.tar.gz	GZIP compressed archive with driver source code
ChangeLog.txt	Release history
Release.txt	Information about the Device Driver Release

The GZIP compressed archive TDRV018-SW-82-SRC.tar.gz contains the following files and directories:

Directory path ‘tdrv018’:

tdrv018.c	Driver source code
tdrv018def.h	Driver include file
tdrv018.h	Driver include file for application program
Makefile	Device driver make file
makenode	Script for device node creation
api/tdrv018api.h	API include file
api/tdrv018api.c	API source file
COPYING	Copy of the GNU Public License (GPL)
example/tdrv018exa.c	Example application
example/Makefile	Example application makefile
include/tpmodule.c	Driver independent library
include/tpmodule.h	Driver independent library header file
include/config.h	Driver independent library header file
include/tpxxhwdep.h	HAL library header file
include/tpxxhwdep.c	HAL library source file

In order to perform an installation, extract all files of the archive TDRV018-SW-82-SRC.tar.gz to the desired target directory. The command ‘tar -xzvf TDRV018-SW-82-SRC.tar.gz’ will extract the files into the local directory.

- Login as *root* and change to the target directory
- Copy tdrv018.h to */usr/include*

### 2.1 Build and Install the Device Driver

- Login as *root*
- Change to the target directory
- To create and install the driver in the module directory */lib/modules/<version>/misc* enter:  
**# make install**
- To update the device driver’s module dependencies, enter:  
**# depmod -aq**

## 2.2 Uninstall the Device Driver

- Login as *root*
- Change to the target directory
- To remove the driver from the module directory */lib/modules/<version>/misc* enter:  
**# make uninstall**

## 2.3 Install Device Driver into the running Kernel

- To load the device driver into the running kernel, login as root and execute the following commands:  
**# modprobe tdrv018drv**
- After the first build or if you are using dynamic major device allocation it is necessary to create new device nodes on the file system. Please execute the script file *makenode* to do this. If your kernel has enabled a device file system (devfs or sysfs) with udev) then you have to skip running the *makenode* script. Instead of creating device nodes from the script the driver itself takes creating and destroying of device nodes in its responsibility.

**# sh makenode**

On success the device driver will create a minor device for each TDRV018 device found. The first TDRV018 device can be accessed with device node */dev/tdrv018\_0*, the second module with device node */dev/tdrv018\_1* and so on.

The assignment of device nodes to physical TDRV018 modules depends on the search order of the PCI bus driver.

## 2.4 Remove Device Driver from the running Kernel

- To remove the device driver from the running kernel login as root and execute the following command:

**# modprobe -r tdrv018drv**

If your kernel has enabled devfs or sysfs (udev), all */dev/tdrv018\_x* nodes will be automatically removed from your file system after this.

**Be sure that the driver isn't opened by any application program. If opened you will get the response "tdrv018drv: Device or resource busy" and the driver will still remain in the system until you close all opened files and execute modprobe -r again.**

## 2.5 Change Major Device Number

This paragraph is only for Linux kernels without dynamic device file system installed. The TDRV018 driver uses dynamic allocation of major device numbers per default. If this isn't suitable for the application it is possible to define a major number for the driver.

To change the major number, edit the file tdrv018def.h, change the following symbol to appropriate value, and enter make install to create a new driver.

TDRV018_MAJOR	Valid numbers are in range between 0 and 255. A value of 0 means dynamic number allocation.
---------------	---

### Example:

```
#define TDRV018_MAJOR 122
```

**Be sure that the desired major number isn't used by other drivers. Please check `/proc/devices` to see which numbers are free.**

# 3 API Documentation

## 3.1 General Functions

### 3.1.1 tdrv018Open

#### NAME

tdrv018Open – opens a device.

#### SYNOPSIS

```
TDRV018_HANDLE tdrv018Open  
(  
    char      *DeviceName  
)
```

#### DESCRIPTION

Before I/O can be performed to a device, a device descriptor must be opened by a call to this function.

#### PARAMETERS

##### *DeviceName*

This parameter points to a null-terminated string that specifies the name of the device. The following device naming must be used:

Device Number	Device Name
1	/dev/tdrv018_0
2	/dev/tdrv018_1

A TXMC633 module is represented by two independent devices. The module's BCC is represented by an independent PCI device, and separate device node is created for the User-FPGA (if the design implements a PCIe endpoint).

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE hdl;

/*
** open the specified device
*/
hdl = tdrv018Open("/dev/tdrv018_0");
if (hdl == NULL)
{
    /* handle open error */
}
```

## RETURNS

A device handle, or NULL if the function fails. An error code will be stored in *errno*.

## ERROR CODES

The error codes are stored in *errno*.

The error code is a standard error code set by the I/O system.

### 3.1.2 tdrv018Close

#### NAME

tdrv018Close – closes a device.

#### SYNOPSIS

```
TDRV018_STATUS tdrv018Close  
(  
    TDRV018_HANDLE     hdl  
)
```

#### DESCRIPTION

This function closes previously opened devices.

#### PARAMETERS

*hdl*

This value specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

#### EXAMPLE

```
#include "tdrv018api.h"  
  
TDRV018_HANDLE     hdl;  
TDRV018_STATUS     result;  
  
/*  
** close the device  
*/  
result = tdrv018Close(hdl);  
if (result != TDRV018_OK)  
{  
    /* handle close error */  
}
```

---

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid

### 3.1.3 tdrv018GetPciInfo

#### NAME

tdrv018GetPciInfo – get information of the module PCI header

#### SYNOPSIS

```
TDRV018_STATUS tdrv018GetPciInfo
(
    TDRV018_HANDLE          hdl,
    TDRV018_PCIINFO_BUF     *pPciInfoBuf
)
```

#### DESCRIPTION

This function returns information of the module PCI header in the provided data buffer.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pPciInfoBuf*

This argument is a pointer to the structure TDRV018\_PCIINFO\_BUF that receives information of the module PCI header.

```
typedef struct
{
    unsigned short    vendorId;
    unsigned short    devicelD;
    unsigned short    subSystemId;
    unsigned short    subSystemVendorId;
    int               pciBusNo;
    int               pciDevNo;
    int               pciFuncNo;
} TDRV018_PCIINFO_BUF;
```

*vendorId*

PCI module vendor ID.

*deviceID*

PCI module device ID

*subSystemID*

PCI module sub system ID

*subSystemVendorID*

PCI module sub system vendor ID

*pciBusNo*

Number of the PCI bus, where the module resides.

*pciDevNo*

PCI device number

*pciFuncNo*

PCI function number

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE      hdl;
TDRV018_STATUS      result;
TDRV018_PCIINFO_BUF pciInfoBuf

/*
** get module PCI information
*/
result = tdrv018GetPciInfo( hdl, &pciInfoBuf );

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid

### 3.1.4 tdrv018GetBoardInfo

#### NAME

tdrv018GetBoardInfo – get information of the board

#### SYNOPSIS

```
TDRV018_STATUS tdrv018GetBoardInfo
(
    TDRV018_HANDLE          hdl,
    unsigned int              *pFpgaStatus,
    unsigned int              *pDipSwitch,
    unsigned int              *pFirmwareVersion
)
```

#### DESCRIPTION

This function returns information about the board status. This function is only supported for TPMC634 (or compatible) devices.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pFpgaStatus*

This argument returns the current FPGA Status. The following values are possible:

Value	Description
TDRV018_FPGASTAT_DONE	DONE Signal State
TDRV018_FPGASTAT_INIT	INIT Signal State

*pDipSwitch*

This argument returns the value of the onboard 4-bit DIP switch. Bit 0 corresponds to DIP switch position 1, bit 1 corresponds to DIP switch position 2 and so on.

*pFirmwareVersion*

This argument returns the firmware version of the PCI target device.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE      hdl;
TDRV018_STATUS      result;
unsigned int          FpgaStatus;
unsigned int          DipSwitch;
unsigned int          FWVersion;

/*
 ** get board information
 */
result = tdrv018GetBoardInfo( hdl, &FpgaStatus, &DipSwitch, &FWVersion );

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_NOSYS	This function is not supported by the device.

### 3.1.5 tdrv018GetBoardName

#### NAME

tdrv018GetBoardName – get Name of the board

#### SYNOPSIS

```
TDRV018_STATUS tdrv018GetBoardName
(
    TDRV018_HANDLE          hdl,
    unsigned char           *pBoardName,
    int                     len
)
```

#### DESCRIPTION

This function returns the name of the board to distinguish between the supported hardware modules and devices.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pBoardName*

This argument returns a null-terminated ASCII string describing the specific hardware module. The following boarding naming scheme is implemented:

Value	Description
“TPMC634”	TPMC634 Device
“TXMC638-BCC”	TXMC638 BCC Device
“TXMC638-FPGA”	TXMC638 User-FPGA Device

*len*

This argument specifies the maximum length available for storing the board name.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE      hdl;
TDRV018_STATUS      result;
char                 BoardName[ 40 ];

/*
 ** get board name
 */
result = tdrv018GetBoardName( hdl, &BoardName, 40 );

if (result == TDRV018_OK)
{
    printf("Board Name: %s\n", BoardName);
} else {
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid

### 3.1.6 tdrv018GetBoardSerial

#### NAME

tdrv018GetBoardSerial – get Serial Number of the board

#### SYNOPSIS

```
TDRV018_STATUS tdrv018GetBoardSerial
(
    TDRV018_HANDLE          hdl,
    unsigned int             *pSerialNumber
)
```

#### DESCRIPTION

This function returns the serial number of the board. This function is only supported by BCC devices.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pSerialNumber*

This argument returns the board serial number as a decimal number.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE      hdl;
TDRV018_STATUS      result;
unsigned int         SerialNumber;

/*
** get board serial number
*/
result = tdrv018GetBoardSerial( hdl, &SerialNumber );

if (result == TDRV018_OK)
{
    printf("Board Serial Number: %d\n", SerialNumber);
} else {
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_NOSYS	This function is not supported by the device.

### 3.1.7 tdrv018GetBoardFWVersion

#### NAME

tdrv018GetBoardFWVersion – get Firmware Version of the board

#### SYNOPSIS

```
TDRV018_STATUS tdrv018GetBoardFWVersion
(
    TDRV018_HANDLE          hdl,
    unsigned int             *pFWVersion
)
```

#### DESCRIPTION

This function returns the Firmware Version of the board. This function is not supported by User-FPGA devices.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pFWVersion*

This argument returns the Firmware Version of the device. For details, please refer to the corresponding hardware user manual.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE      hdl;
TDRV018_STATUS      result;
unsigned int         FWVersion;

/*
 ** get board serial number
 */
result = tdrv018GetBoardFWVersion( hdl, &FWVersion );

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_NOSYS	This function is not supported by the device.

### 3.1.8 tdrv018GetFpgaStatus

#### NAME

tdrv018GetFpgaStatus – get status of the User-FPGA

#### SYNOPSIS

```
TDRV018_STATUS tdrv018GetFpgaStatus
(
    TDRV018_HANDLE          hdl,
    unsigned int             *pFpgaStatus
)
```

#### DESCRIPTION

This function returns the configuration status of the User-FPGA. This function is not supported by User-FPGA devices.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pFpgaStatus*

This argument returns the current FPGA Status. The following values are possible:

Value	Description
TDRV018_FPGASTAT_DONE	DONE Signal State
TDRV018_FPGASTAT_INIT	INIT Signal State

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE      hdl;
TDRV018_STATUS      result;
unsigned int         FpgaStatus;

/*
 ** get FPGA Status
 */
result = tdrv018GetFpgaStatus( hdl, &FpgaStatus );

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_NOSYS	This function is not supported by the device.

## 3.2 Local Bus Control Functions

The Local Bus Control Functions are only supported for TPMC634 (or compatible) devices.

### 3.2.1 tdrv018LocalBusControl

#### NAME

tdrv018LocalBusControl – Configure and control the Local Bus

#### SYNOPSIS

```
TDRV018_STATUS tdrv018LocalBusControl  
(  
    TDRV018_HANDLE      hdl,  
    unsigned int          ControlFlags  
)
```

#### DESCRIPTION

This function controls the Local Bus Interface.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*ControlFlags*

This value specifies a 32bit unsigned int value, which contains the combined Local Bus Control Flags. The following OR'ed values are possible:

Value	Description
TDRV018_LOCALBUS_RESET	If set, the Local Bus Reset signal is asserted.
TDRV018_LOCALBUS_TOUT_DIS	If set, the Local Bus Timeout is disabled.
TDRV018_LOCALBUS_PLLRESET	If set, the Local Bus PLL is held in reset mode.

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;

/*
 ** Perform a Local Bus Reset
 */
/* assert Local Bus Reset */
result = tdrv018LocalBusControl( hdl, TDRV018_LOCALBUS_RESET );
if (result != TDRV018_OK)
{
    /* handle error */
}

... wait some time ...

/* de-assert Local Bus Reset */
result = tdrv018LocalBusControl( hdl, 0 );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_INVAL	The specified flags are invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

### 3.2.2 tdrv018LocalBusStatus

#### NAME

tdrv018LocalBusStatus – Read Status of the Local Bus

#### SYNOPSIS

```
TDRV018_STATUS tdrv018LocalBusStatus
(
    TDRV018_HANDLE      hdl,
    unsigned int         *pStatus
)
```

#### DESCRIPTION

This function reads the status of the Local Bus Interface. The Event flags are cleared after execution of this function.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pStatus*

This argument returns the Local Bus Status and Event Flags. The following OR'ed values are possible:

Value	Description
TDRV018_LOCALBUS_PLLLOCKED	The PLL is currently locked.
TDRV018_LOCALBUS_RESETACTIVE	The Local Bus Reset is currently active.
TDRV018_LOCALBUS_MASTERABORT	A Master Abort has been detected.
TDRV018_LOCALBUS_TARGETERROR	A Target Error has been detected.
TDRV018_LOCALBUS_PLLOSSOFLOCK	A Loss-of-Lock has been detected.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
Unsigned int       Status;

/*
** Check the Local Bus Status
*/
result = tdrv018LocalBusStatus( hdl, &Status );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

## 3.3 EEPROM Access Functions

The EEPROM Access Functions are only supported for TPMC634 (or compatible) devices.

### 3.3.1 tdrv018EepromWrite

#### NAME

tdrv018EepromWrite – Write 16bit value to PCI Configuration EEPROM

#### SYNOPSIS

```
TDRV018_STATUS tdrv018EepromWrite
(
    TDRV018_HANDLE      hdl,
    unsigned int         Offset,
    unsigned short       Value
)
```

#### DESCRIPTION

This function writes an *unsigned short* (16bit) value to a specific PCI Configuration EEPROM memory offset.

**Please note that the PCI target device reloads the new configuration from the EEPROM after a PCI reset, i.e. the system must be rebooted to make the changes take effect.**

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*Offset*

Specifies the offset into the PCI Configuration EEPROM, where the supplied data word should be written. The offset must be specified as word-address.

Following offsets are available:

Offset	Access
00h – 01h	R
02h – 7Fh	R / W

Refer to the TPMC634 User Manual for detailed information on these registers.

---

**Value**

This value specifies a 16bit word that should be written to the specified offset.

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
unsigned int       Offset;
unsigned short     Value;

/*
 ** Change the Subsystem Vendor ID to TEWS Technologies (0x1498)
 */
Offset = 0x05;
Value  = 0x1498;

result = tdrv018EepromWrite( hdl, Offset, Value );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_INVAL	The specified offset is invalid, or read-only.
TDRV018_ERR_NOSYS	This function is not supported by the device.

### 3.3.2 tdrv018EepromRead

#### NAME

tdrv018EepromRead – Read 16bit value from PCI Configuration EEPROM

#### SYNOPSIS

```
TDRV018_STATUS tdrv018EepromRead
(
    TDRV018_HANDLE      hdl,
    unsigned int          Offset,
    unsigned short        *pValue
)
```

#### DESCRIPTION

This function reads an *unsigned short* (16bit) value from a specific PCI Configuration EEPROM memory offset.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*Offset*

Specifies the offset into the PCI Configuration EEPROM, where the supplied data word should be written. The offset must be specified as word-address.

Following offsets are available:

Offset	Access
00h – 01h	R
02h – 7Fh	R / W

Refer to the TPMC634 User Manual for detailed information on these registers.

*pValue*

This value is a pointer to an *unsigned short* value, which receives the 16bit word.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
unsigned int       Offset;
unsigned short     Value;

/*
 ** Read Subsystem ID
 */
Offset = 0x04;

result = tdrv018EepromRead( hdl, Offset, &Value );
if (result == TDRV018_OK)
{
    printf( "Value = 0x%04X\n", Value );
} else {
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_INVAL	The specified offset is invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

## 3.4 Pull-Resistor Configuration Functions

The Pull-Resistor Configuration Functions are only supported for TXMC633 and TXMC635 (or compatible) BCC devices.

### 3.4.1 tdrv018PullConfigSet

#### NAME

tdrv018PullConfigSet – Configure the pull-resistor settings

#### SYNOPSIS

```
TDRV018_STATUS tdrv018PullConfigSet
(
    TDRV018_HANDLE      hdl,
    int                  PullControl,
    unsigned int          PullConfig
)
```

#### DESCRIPTION

This function writes the configuration value into the Pull Resistor Configuration Register of the selected device.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*PullControl*

This parameter specifies if the Pull-Resistor Configuration shall be controlled by the User-FPGA or by the PullConfig value. The following values are possible:

Value	Description
TDRV018_PULLCNT_USERFPGA	Pull-Configuration is controlled by the User-FPGA
TDRV018_PULLCNT_BCC	Pull-Configuration is controlled by the BCC and the PullConfig value.

*PullConfig*

This value specifies a 32bit unsigned int value, which directly corresponds to the Pull Resistor Configuration Register of the supported hardware module. For details, please refer to the corresponding hardware user-manual.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;

/*
 ** Set the pull-resistor configuration
 */
result = tdrv018PullConfigSet( hdl, 0x000000AA );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

### 3.4.2 tdrv018PullConfigGet

#### NAME

tdrv018PullConfigGet – Read the current pull-resistor configuration

#### SYNOPSIS

```
TDRV018_STATUS tdrv018PullConfigGet
(
    TDRV018_HANDLE      hdl,
    int                 *pPullControl,
    unsigned int         *pPullConfig
)
```

#### DESCRIPTION

This function reads the configuration value from the Pull Resistor Configuration Register of the selected device.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pPullControl*

This parameter specifies if the Pull-Resistor Configuration is controlled by the User-FPGA or by the PullConfig value. The following values are possible:

Value	Description
TDRV018_PULLCNT_USERFPGA	Pull-Configuration is controlled by the User-FPGA
TDRV018_PULLCNT_BCC	Pull-Configuration is controlled by the BCC and the PullConfig value.

*pPullConfig*

This value specifies a pointer to a 32bit unsigned int value, which receives the content of the Pull Resistor Configuration Register of the supported hardware module. For details, please refer to the corresponding hardware user-manual.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
int                PullControl;
unsigned int       PullConfig;

/*
 ** Read the pull-resistor configuration
 */
result = tdrv018PullConfigGet( hdl, &PullControl, &PullConfig );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

## 3.5 FPGA Programming Functions

### 3.5.1 tdrv018ProgSpiFlashFromFile

#### NAME

tdrv018ProgSpiFlashFromFile – Program the SPI Flash from a supplied bitstream file

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ProgSpiFlashFromFile
(
    TDRV018_HANDLE      hdl,
    char                *pFilename
)
```

#### DESCRIPTION

This function writes the content of a supplied binary configuration bitstream file (.bin) into the onboard SPI configuration flash. The FPGA is not affected by this function. To initiate the FPGA configuration, use the function tdrv018ConfigFromSpiFlash().

**Only one programming function may be executed at once.**

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pFilename*

This value is a pointer to a null-terminated character string, specifying the binary configuration bitstream file name (.bin).

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;

/*
 ** Program the SPI Configuration Flash from a file
 */
result = tdrv018ProgSpiFlashFromFile( hdl, "tpmc634fpga.bin" );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_IO	Error during SPI transfer

### 3.5.2 tdrv018ProgSpiFlash

#### NAME

tdrv018ProgSpiFlash – Program the SPI Flash

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ProgSpiFlash
(
    TDRV018_HANDLE      hdl,
    unsigned char        *pData,
    unsigned int         numBytes
)
```

#### DESCRIPTION

This function writes supplied configuration data into the onboard SPI configuration flash. The FPGA is not affected by this function. To initiate the FPGA configuration, use the function tdrv018ConfigFromSpiFlash().

**Only one programming function may be executed at once.**

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pData*

This value is a pointer to the configuration data, residing in memory.

*numBytes*

This value specifies the number of bytes to be written into the SPI flash.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
unsigned char      *pData;
unsigned int       numBytes;

/*
 ** Program the SPI Configuration Flash from a memory location
 */

/* allocate and fill the memory area */
numBytes = ...;
pData = (unsigned char*)malloc( numBytes );
...

result = tdrv018ProgSpiFlash( hdl, pData, numBytes );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_IO	Error during SPI transfer

### 3.5.3 tdrv018ProgFpgaFromFile

#### NAME

tdrv018ProgFpgaFromFile – Program the FPGA from a supplied bitstream file using Select Map

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ProgFpgaFromFile
(
    TDRV018_HANDLE      hdl,
    char                *pFilename
    int                 timeout
)
```

#### DESCRIPTION

This function writes the content of a supplied configuration bitstream file directly into the FPGA using Select Map. The FPGA is not functional during the programming process.

The PCI Setup of a directly attached User-FPGA is lost after reconfiguration, so the device is not accessible anymore. Assuming no changes regarding the PCI setup (number and size of base address registers), the PCI header can be restored using API function tdrv018RestorePciHeader.

**Only one programming function may be executed at once.**

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pFilename*

This value is a pointer to a null-terminated character string, specifying the configuration bitstream file name.

*timeout*

This value specifies the timeout in milliseconds the function will wait for the FPGA loading to finish, i.e. the DONE signal switches to HIGH. The granularity depends on the operating system. To wait indefinitely, specify -1 as timeout parameter.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;

/*
** Directly program the FPGA from a file, wait up to 1 second for DONE
*/
result = tdrv018ProgFpgaFromFile( hdl, "tpmc634fpga.bin", 1000 );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_IO	Error during FPGA Configuration. DONE remained LOW.

### 3.5.4 tdrv018ProgFpga

#### NAME

tdrv018ProgFpga – Program the FPGA using Select Map

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ProgFpga
(
    TDRV018_HANDLE      hdl,
    unsigned char        *pData,
    unsigned int         numBytes,
    int                  timeout
)
```

#### DESCRIPTION

This function writes the content of a supplied configuration bitstream file directly into the FPGA using Select Map. The FPGA is not functional during the programming process.

The PCI Setup of a directly attached User-FPGA is lost after reconfiguration, so the device is not accessible anymore. Assuming no changes regarding the PCI setup (number and size of base address registers), the PCI header can be restored using API function tdrv018RestorePciHeader.

**Only one programming function may be executed at once.**

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pFilename*

This value is a pointer to a null-terminated character string, specifying the configuration bitstream file name.

*pData*

This value is a pointer to the configuration data, residing in memory.

*numBytes*

This value specifies the number of bytes to be written into the FPGA.

*timeout*

This value specifies the timeout in milliseconds the function will wait for the FPGA loading to finish, i.e. the DONE signal switches to HIGH. The granularity depends on the operating system. To wait indefinitely, specify -1 as timeout parameter.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
unsigned char      *pData;
unsigned int       numBytes;

/*
 ** Directly program the FPGA, wait up to 1 second for DONE
 */
/* allocate and fill the memory area */
numBytes = ...;
pData = (unsigned char*)malloc( numBytes );
...

result = tdrv018ProgFpga( hdl, pData, numBytes, 1000 );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_IO	Error during FPGA Configuration. DONE remained LOW.

### 3.5.5 tdrv018ConfigFromSpiFlash

#### NAME

tdrv018ConfigFromSpiFlash – Start loading the FPGA from the SPI Flash

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ConfigFromSpiFlash
(
    TDRV018_HANDLE      hdl,
    int                  timeout
)
```

#### DESCRIPTION

This function starts loading the FPGA bitstream from the SPI Flash into the FPGA.

The PCI Setup of a directly attached User-FPGA is lost after reconfiguration, so the device is not accessible anymore. Assuming no changes regarding the PCI setup (number and size of base address registers), the PCI header can be restored using API function tdrv018RestorePciHeader.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*timeout*

This value specifies the timeout in milliseconds the function will wait for the FPGA loading to finish, i.e. the DONE signal switches to HIGH. The granularity depends on the operating system. To wait indefinitely, specify -1 as timeout parameter.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;

/*
 ** Load the FPGA from the SPI Flash, wait up to 1 second for DONE
 */
result = tdrv018ConfigFromSpiFlash( hdl, 1000 );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_IO	Error during FPGA Configuration. DONE remained LOW.

### 3.5.6 tdrv018PcieLinkEnable

#### NAME

tdrv018PcieLinkEnable – Enable PCIe Link for the User-FPGA

#### SYNOPSIS

```
TDRV018_STATUS tdrv018PcieLinkEnable
(
    TDRV018_HANDLE      hdl
)
```

#### DESCRIPTION

This function gracefully enables the PCIe Link for the User-FPGA. This function is only supported by BCC devices. Reconfiguring a User-FPGA might result in PCIe errors, which might cause unpredictable behavior of the overall system.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

#### EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;

/*
 ** Enable the PCIe Link of the User-FPGA
 */
result = tdrv018PcieLinkEnable( hdl );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

---

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

### 3.5.7 tdrv018PcieLinkDisable

#### NAME

tdrv018PcieLinkDisable – Disable PCIe Link for the User-FPGA

#### SYNOPSIS

```
TDRV018_STATUS tdrv018PcieLinkDisable
(
    TDRV018_HANDLE      hdl
)
```

#### DESCRIPTION

This function gracefully disables the PCIe Link for the User-FPGA. This function is only supported by BCC devices. Reconfiguring a User-FPGA might result in PCIe errors, which might cause unpredictable behavior of the overall system. So before starting a configuration which might affect the PCIe Link State of the User-FPGA, disabling the PCIe link is suggested.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

#### EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;

/*
 ** Disable the PCIe Link of the User-FPGA
 */
result = tdrv018PcieLinkDisable( hdl );
if (result != TDRV018_OK)
{
    /* handle error */
}
```

---

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

### 3.5.8 tdrv018RestorePciHeader

#### NAME

tdrv018RestorePciHeader – Restore the PCI header of the User-FPGA

#### SYNOPSIS

```
TDRV018_STATUS tdrv018RestorePciHeader  
(  
    TDRV018_HANDLE     hdl  
)
```

#### DESCRIPTION

This function restores the PCI header of the User-FPGA using values stored upon driver start. After reconfiguration of a User-FPGA, the PCI header configuration is lost. To allow further accesses to the User-FPGA, the PCI header must be restored using this function. This function is only supported by User-FPGA devices.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

#### EXAMPLE

```
#include "tdrv018api.h"  
  
TDRV018_HANDLE     hdl;  
TDRV018_STATUS     result;  
  
/*  
 ** Restore the PCI header of the User-FPGA  
 */  
result = tdrv018RestorePciHeader( hdl );  
if (result != TDRV018_OK)  
{  
    /* handle error */  
}
```

---

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

## 3.6 Register Access Functions

### 3.6.1 tdrv018Read8

#### NAME

tdrv018Read8 – read 8-bit values from PCI BAR space

#### SYNOPSIS

```
TDRV018_STATUS tdrv018Read8
(
    TDRV018_HANDLE      hdl,
    int                  pciResource,
    int                  offset,
    int                  numItems,
    unsigned char        *pData
)
```

#### DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using single byte (8-bit) accesses.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

PCI Base Address Register	PCI Address-Type	TDRV018 Resource
0	reserved	TDRV018_RES_MEM_1
1	reserved	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (8-bit) to read.

*pData*

This argument is a pointer to an unsigned char buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

## EXAMPLE

```
#include "tdrv018api.h"

#define NUM_ITEMS 256

TDRV018_HANDLE hdl;
TDRV018_STATUS result;
int offset;
unsigned char dataBuf[NUM_ITEMS];

offset = 0x0000;
/*
** read 256 Bytes from the User FPGA Register Area
*/
result = tdrv018Read8( hdl, TDRV018_RES_MEM_3, offset, NUM_ITEMS, dataBuf
);

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.2 tdrv018ReadBE16

#### NAME

tdrv018ReadBE16 – read 16-bit values from PCI BAR space, Big Endian Mode

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ReadBE16
```

```
(  
    TDRV018_HANDLE      hdl,  
    int                  pciResource,  
    int                  offset,  
    int                  numItems,  
    unsigned short       *pData  
)
```

#### DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using 16-bit accesses. The values are returned as Big Endian values, that means on Intel x86 architectures the multibyte data will be byte-swapped.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

PCI Base Address Register	PCI Address-Type	TDRV018 Resource
0	reserved	TDRV018_RES_MEM_1
1	reserved	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (16-bit) to read.

*pData*

This argument is a pointer to an unsigned short buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

## EXAMPLE

```
#include "tdrv018api.h"

#define NUM_ITEMS 128

TDRV018_HANDLE hdl;
TDRV018_STATUS result;
int offset;
unsigned short dataBuf[NUM_ITEMS];

offset = 0x00;
/*
** read 256 Bytes from the User FPGA Register Area
*/
result = tdrv018ReadBE16( hdl, TDRV018_RES_MEM_3, offset, NUM_ITEMS,
dataBuf);

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.3 tdrv018ReadLE16

#### NAME

tdrv018ReadLE16 – read 16-bit values from PCI BAR space, Little Endian Mode

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ReadLE16
```

```
(  
    TDRV018_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned short      *pData  
)
```

#### DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using 16-bit accesses. The values are returned as Little Endian values, that means on Intel x86 architectures the multibyte data will not be byte-swapped.

The register sets of FPGA onchip bus slave devices and DRAM memory areas can be accessed via addressable data regions in PCI BAR space.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (16-bit) to read.

*pData*

This argument is a pointer to an unsigned short buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

## EXAMPLE

```
#include "tdrv018api.h"

#define NUM_ITEMS 128

TDRV018_HANDLE hdl;
TDRV018_STATUS result;
int offset;
unsigned short dataBuf[NUM_ITEMS];

offset = 0x00;
/*
** read 256 Bytes from the User FPGA Register Area
*/
result = tdrv018ReadLE16( hdl, TDRV018_RES_MEM_3, offset, NUM_ITEMS,
dataBuf);

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.4 tdrv018ReadBE32

#### NAME

tdrv018ReadBE32 – read 32-bit values from PCI BAR space, Big Endian Mode

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ReadBE32
```

```
(  
    TDRV018_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned int        *pData  
)
```

#### DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using 32-bit accesses. The values are returned as Big Endian values, that means on Intel x86 architectures the multibyte data will be byte-swapped.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (32-bit) to read.

*pData*

This argument is a pointer to an unsigned int buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

---

## EXAMPLE

```
#include "tdrv018api.h"

#define NUM_ITEMS 2

TDRV018_HANDLE hdl;
TDRV018_STATUS result;
int offset;
unsigned int dataBuf[NUM_ITEMS];

offset = 0x00;
/*
 ** read I/O Input Registers of the FPGA Example Design
 */
result = tdrv018ReadBE32( hdl, TDRV018_RES_MEM_3, offset, NUM_ITEMS,
dataBuf);

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.5 tdrv018ReadLE32

#### NAME

tdrv018ReadLE32 – read 32-bit values from PCI BAR space, Little Endian Mode

#### SYNOPSIS

```
TDRV018_STATUS tdrv018ReadLE32
```

```
(  
    TDRV018_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned int        *pData  
)
```

#### DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using 32-bit accesses. The values are returned as Little Endian values, that means on Intel x86 architectures the multibyte data will not be byte-swapped.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

#### *offset*

This argument specifies the start offset within the PCI BAR space.

#### *numItems*

This argument specifies the number of items (32-bit) to read.

#### *pData*

This argument is a pointer to an unsigned int buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

## EXAMPLE

```
#include "tdrv018api.h"

#define NUM_ITEMS 2

TDRV018_HANDLE hdl;
TDRV018_STATUS result;
int offset;
unsigned int dataBuf[NUM_ITEMS];

offset = 0x00;
/*
** read I/O Input Registers of the FPGA Example Design
*/
result = tdrv018ReadLE32( hdl, TDRV018_RES_MEM_3, offset, NUM_ITEMS,
dataBuf);

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.6 tdrv018Write8

#### NAME

tdrv018Write8 – write 8-bit values to the PCI BAR space

#### SYNOPSIS

TDRV018\_STATUS tdrv018Write8

```
(  
    TDRV018_HANDLE      hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned char       *pData  
)
```

#### DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using single byte (8-bit) accesses.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (8-bit) to write.

*pData*

This argument is a pointer to an unsigned char buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

## EXAMPLE

```
#include "tdrv018api.h"

#define NUM_ITEMS 4

TDRV018_HANDLE hdl;
TDRV018_STATUS result;
int offset;
unsigned char dataBuf[NUM_ITEMS];

dataBuf[0] = 0xAA;
dataBuf[1] = 0x55;
...

offset = 0xF8;
/*
** write 4 bytes to a 32bit Scratchpad Register
*/
result = tdrv018Write8( hdl, TDRV018_RES_MEM_3, offset, NUM_ITEMS, dataBuf
);

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.7 tdrv018WriteBE16

#### NAME

tdrv018WriteBE16 – write 16-bit values to the PCI BAR space, Big Endian Mode

#### SYNOPSIS

```
TDRV018_STATUS tdrv018WriteBE16
```

```
(  
    TDRV018_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned short      *pData  
)
```

#### DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using 16-bit accesses.

The values are written in Big Endian Mode, that means on Intel x86 architectures the multibyte data will be byte-swapped.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (16-bit) to write.

*pData*

This argument is a pointer to an unsigned short buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

## EXAMPLE

```
#include "tdrv018api.h"

#define NUM_ITEMS 2

TDRV018_HANDLE hdl;
TDRV018_STATUS result;
int offset;
unsigned short dataBuf[NUM_ITEMS];

dataBuf[0] = 0xAA55;
dataBuf[1] = 0x55AA;
...

offset = 0xF8;
/*
** write 2 datawords to a 32bit Scratchpad Register
*/
result = tdrv018WriteBE16(hdl, TDRV018_RES_MEM_3, offset, NUM_ITEMS,
dataBuf);

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.8 tdrv018WriteLE16

#### NAME

tdrv018WriteLE16 – write 16-bit values to the PCI BAR space, Little Endian Mode

#### SYNOPSIS

```
TDRV018_STATUS tdrv018WriteLE16
```

```
(  
    TDRV018_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned short      *pData  
)
```

#### DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using 16-bit accesses.

The values are written in Little Endian Mode, that means on Intel x86 architectures the multibyte data will not be byte-swapped.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (16-bit) to write.

*pData*

This argument is a pointer to an unsigned short buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

## EXAMPLE

```
#include "tdrv018api.h"

#define NUM_ITEMS 2

TDRV018_HANDLE hdl;
TDRV018_STATUS result;
int offset;
unsigned short dataBuf[NUM_ITEMS];

dataBuf[0] = 0xAA55;
dataBuf[1] = 0x55AA;
...

offset = 0xF8;
/*
** write 2 data words to a 32bit Scratchpad Register
*/
result = tdrv018WriteLE16(hdl, TDRV018_RES_MEM_3, offset, NUM_ITEMS,
dataBuf);

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.9 tdrv018WriteBE32

#### NAME

tdrv018WriteBE32 – write 32-bit values to the PCI BAR space, Big Endian Mode

#### SYNOPSIS

```
TDRV018_STATUS tdrv018WriteBE32
```

```
(  
    TDRV018_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned int        *pData  
)
```

#### DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using 32-bit accesses.

The values are written in Big Endian Mode, that means on Intel x86 architectures the multibyte data will be byte-swapped.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (32-bit) to write.

*pData*

This argument is a pointer to an unsigned short buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
int                offset;
unsigned int       data;

data    = 0x12345678;
offset = 0xF8;
/*
** Write Test data into 32bit Scratchpad Register
*/
result = tdrv018WriteBE32( hdl, TDRV018_RES_MEM_3, offset, 1, &data );

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

### 3.6.10 tdrv018WriteLE32

#### NAME

tdrv018WriteLE32 – write 32-bit values to the PCI BAR space, Little Endian Mode

#### SYNOPSIS

```
TDRV018_STATUS tdrv018WriteLE32
```

```
(  
    TDRV018_HANDLE      hdl,  
    int                  pciResource,  
    int                  offset,  
    int                  numItems,  
    unsigned int          *pData  
)
```

#### DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using 32-bit accesses.

The values are written in Big Endian Mode, that means on Intel x86 architectures the multibyte data will not be byte-swapped.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

*offset*

This argument specifies the start offset within the PCI BAR space.

*numItems*

This argument specifies the number of items (32-bit) to write.

*pData*

This argument is a pointer to an unsigned short buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
int                offset;
unsigned int       data;

data    = 0x12345678;
offset = 0xF8;
/* Write Test data into 32bit Scratchpad Register */
result = tdrv018WriteLE32( hdl, TDRV018_RES_MEM_3, offset, 1, &data );

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_ACCESS	Specified PCI resource not available or reserved
TDRV018_ERR_INVAL	The specified access range exceeds PCI BAR limits

## 3.7 Resource Mapping Functions

### 3.7.1 tdrv018PciResourceMap

#### NAME

tdrv018PciResourceMap – map a PCI resource directly into the process context

#### SYNOPSIS

```
TDRV018_STATUS tdrv018PciResourceMap
(
    TDRV018_HANDLE      hdl,
    int                 pciResource,
    unsigned char       **pPtr,
    unsigned int         *pSize
)
```

#### DESCRIPTION

This function maps the specified PCI resource of the hardware module directly into the process context. The retrieved pointer can be used for direct non-cached register access.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pciResource*

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCI Configuration EEPROM. Therefore the following table is just an example how the PCI Base Address Registers could be used for a TPMC634.

<b>PCI Base Address Register</b>	<b>PCI Address-Type</b>	<b>TDRV018 Resource</b>
0	<i>reserved</i>	TDRV018_RES_MEM_1
1	<i>reserved</i>	TDRV018_RES_MEM_2
2	MEM	TDRV018_RES_MEM_3
3	MEM ( <i>not used</i> )	TDRV018_RES_MEM_4
4	MEM ( <i>not used</i> )	TDRV018_RES_MEM_5
5	MEM ( <i>not used</i> )	TDRV018_RES_MEM_6

#### *pPtr*

This argument is a pointer to an unsigned char pointer that receives the start address of the mapped PCI resource.

#### *pSize*

This argument returns the size of the mapped PCI resource in bytes.

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
unsigned char     *pReg;
unsigned int       size;

/*
 ** map first memory PCI resource
 */
result = tdrv018PciResourceMap( hdl, TDRV018_RES_MEM_3, &pReg, &size );

if (result != TDRV018_OK)
{
    /* handle error */
}
```

---

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_NOMEM	Unable to allocate memory

### 3.7.2 tdrv018PciResourceUnmap

#### NAME

tdrv018PciResourceUnmap – unmap a previously mapped PCI resource

#### SYNOPSIS

```
TDRV018_STATUS tdrv018PciResourceUnmap
(
    TDRV018_HANDLE      hdl,
    unsigned char        *pPtr
)
```

#### DESCRIPTION

This function unmaps a previously mapped PCI resource, freeing the system resources used for this mapping.

#### PARAMETERS

*hdl*

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

*pPtr*

This argument is a pointer to an unsigned char pointer that represents the start address of the previously mapped PCI resource. This pointer must have been received from the corresponding mapping function.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
unsigned char      *pReg;

/*
 ** unmap a previously mapped PCI resource
 */
result = tdrv018PciResourceUnmap( hdl, pReg );

if (result != TDRV018_OK)
{
    /* handle error */
}
```

## RETURN VALUE

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV018_ERR_INVAL	Invalid pointer specified

## 3.8 Interrupt Functions

### 3.8.1 tdrv018InterruptWait

#### NAME

tdrv018InterruptWait – Wait for incoming Local Interrupt Source

#### SYNOPSIS

```
TDRV018_STATUS tdrv018InterruptWait
(
    TDRV018_HANDLE      hdl,
    uint32_t             interruptMask,
    uint32_t             *pInterruptOccurred,
    int                  timeout
);
```

#### DESCRIPTION

This function enables the specified local interrupt sources, and waits for these Local Interrupt Sources to arrive. After an interrupt has arrived, the corresponding occurred local interrupt source is disabled. Multiple functions may wait for the same interrupt source to occur.

**The delay between an incoming interrupt and the return of the described function is system-dependent, and is most likely several microseconds.**

**For high interrupt load, a customized device driver should be used which serves the module-specific functionality directly on interrupt level.**

#### PARAMETERS

##### *hdl*

This value specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

##### *interruptMask*

This parameter specifies specific interrupt bits to wait for. The function returns if at least one of the specified interrupt sources is detected. The possible values depend on the used hardware module, and directly relate to the interrupt status register specified using tdrv018InterruptConfig. For TPMC634, the following values are possible:

Value	Description
TDRV018_INTSTAT_LBUSR	User FPGA Interrupt
TDRV018_INTSTAT_LBERR	Local Bus Error Interrupt

*pInterruptOccurred*

If at least one of the specified interrupt sources occurs, the value is returned through this pointer.

*timeout*

This value specifies the timeout in milliseconds the function will wait for the interrupt to arrive. The granularity depends on the operating system. To wait indefinitely, specify -1 as timeout parameter.

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
unsigned int       interruptMask;
unsigned int       interruptOccurred;

/*
** Wait at least 5 seconds for incoming Local Bus User Interrupt
*/
interruptMask = TDRV018_INTSTAT_LBUSR;
result = tdrv018InterruptWait(    hdl,
                               interruptMask,
                               &interruptOccurred,
                               5000 );
if (result == TDRV018_OK)
{
    /* Interrupt arrived. */ */
    /* Now acknowledge interrupt source in FPGA logic */ */
    /* to clear the Local Interrupt Source. */ */
    /* Use tdrv018Read and tdrv018Write functions for */ */
    /* register access. */ */
} else {
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_TIMEOUT	The specified timeout occurred.

### 3.8.2 tdrv018InterruptRegisterCallbackThread

#### NAME

tdrv018InterruptRegisterCallbackThread – Register a User Callback Function for Interrupt Handling

#### SYNOPSIS

```
TDRV018_STATUS tdrv018InterruptRegisterCallbackThread
(
    TDRV018_HANDLE      hdl,
    int                 threadPriority,
    int                 stackSize,
    unsigned int         interruptMask,
    FUNCINTCALLBACK     callbackFunction,
    void                *funcparam,
    TDRV018_HANDLE      *pCallbackHandle
)
```

#### DESCRIPTION

This function registers a user callback function which is executed after detection of the specified interrupt source. Multiple callback functions can be registered to each interrupt source. The callback function is executed in a high-priority thread context, so using TDRV018 device driver functions is allowed. The callback function should be kept as short as possible. The specified callback function is executed with the occurred interrupt bits and the specified function parameter as function arguments. Additionally, a status value is passed to the callback function for proper error handling.

**The delay between an incoming interrupt and the execution of the callback function is system-dependent, and is most likely several microseconds.**

**For high interrupt load, a customized device driver should be used which serves the module-specific functionality directly on interrupt level.**

#### PARAMETERS

*hdl*

This value specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

#### *threadPriority*

This parameter specifies the priority to be used for the callback thread. Possible values are:

Value	Description
TDRV018_PRIORITY_NORMAL	Normal Thread Priority
TDRV018_PRIORITY_HIGH	High Thread Priority
TDRV018_PRIORITY_LOW	Low Thread Priority

Other values might be possible, depending on the used operating system.

#### *threadSize*

This parameter specifies the stack size to be used for the callback tread. The value is specified in bytes.

#### *interruptMask*

This parameter specifies specific interrupt bits to handle. The callback function is executed if at least one of the specified interrupt sources occurred. The following values are possible:

Value	Description
TDRV018_INTSTAT_LBUSR	User FPGA Interrupt
TDRV018_INTSTAT_LBERR	Local Bus Error Interrupt

#### *callbackFunction*

This parameter is a function pointer to the user callback function. The callback function pointer is defined as follows:

```
typedef void(*FUNCINTCALLBACK)( TDRV018_HANDLE hdl,
                                unsigned int interruptOccurred,
                                void *param,
                                TDRV018_STATUS status );
```

#### *hdl*

This parameter specifies a device handle which can be used for hardware access or other API functions by the callback function.

#### *interruptOccurred*

This parameter is a 32bit value reflecting the occurred interrupts. Possible values correspond to the *interruptMask*.

#### *param*

This parameter is the user-specified *funcparam* value (see below) which has been specified on callback registration. This value can be used to pass a pointer to a specific control structure, to supply the callback function with specific information.

#### *status*

This parameter hands over interrupt callback status information. The callback function needs to check this parameter. If the specified interrupt source has occurred properly, and no errors were detected, this parameter is TDRV018\_OK. If this parameter differs from TDRV018\_OK, an internal error has been detected and the callback handling is stopped. The callback function must implement an appropriate error handling.

---

*funcparam*

This value specifies a user parameter, which will be handed over to the callback function on execution. This parameter can be used to pass a pointer to a specific control structure used by the callback function.

*pCallbackHandle*

This value specifies a pointer to a handle, where the callback handle will be returned. This callback handle must be used to unregister a callback function.

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE    hdl;
TDRV018_STATUS    result;
unsigned int       interruptMask;
USER_DATA_AREA    userDataArea[2];
TDRV018_HANDLE    callbackHandle[2];

/* forward declaration of callback functions */
void callback_INPUT( TDRV018_HANDLE hdl,
                     unsigned int      interruptOccurred,
                     void             *param,
                     TDRV018_STATUS   status );

void callback_INPUTdirect( TDRV018_HANDLE      hdl,
                          unsigned int        interruptOccurred,
                          void              *param,
                          TDRV018_STATUS    status );
...
```

```
/*
 ** Register callback function for INPUT (LBUSR)
 ** Use a "normal" priority, and 64KB stack.
 */
interruptMask = TDRV018_INTSTAT_LBUSR;
result = tdrv018InterruptRegisterCallbackThread( hdl,
                                                TDRV018_PRIORITY_NORMAL,
                                                0x10000,
                                                interruptMask,
                                                callback_INPUT,
                                                &userDataArea[0],
                                                &callbackHandle[0] );
...
...
if (result != TDRV018_OK)
{
    /* handle error */
}

/*
** Map Device Register Space for direct access
*/
result = tdrv018PciResourceMap( hdl,
                                TDRV018_RES_MEM_3,
                                &userDataArea[1].pRegSpace,
                                &userDataArea[1].resSize );
if (result != TDRV018_OK)
{
    /* handle error */
}

...
/*
** Register callback function for INPUT (LBUSR), using direct access
** Use a "normal" priority, and 64KB stack.
*/
interruptMask = TDRV018_INTSTAT_LBUSR;
result = tdrv018InterruptRegisterCallbackThread( hdl,
                                                TDRV018_PRIORITY_NORMAL,
                                                0x10000,
                                                interruptMask,
                                                callback_INPUTdirect,
                                                &userDataArea[1],
                                                &callbackHandle[1] );
```

```

/*
** Initialize the Input Interrupt functionality, using register accesses.
** Refer to the FPGA Example documentation for register description.
*/
...
...

/*
** Callback Function, using API Functions for Register Access
*/
void callback_INPUT( TDRV018_HANDLE hdl,
                     unsigned int    interruptOccurred,
                     void          *param,
                     TDRV018_STATUS status )
{
    TDRV018_STATUS result;
    USER_DATA_AREA *pUsrData = (USER_DATA_AREA*)param;
    unsigned int    intstat;

    if (status != TDRV018_OK)
    {
        /* handle error status */
    }
    /* read Input Interrupt Status Register */
    result = tdrv018WriteLE32(      hdl,
                                   TDRV018_RES_MEM_3,
                                   0x28,
                                   1,
                                   &intstat );

    if (intstat != 0)
    {
        printf("[Input Interrupt]\n");

        /* Acknowledge INPUT interrupt source by writing to
        ** "Interrupt Status Register" */
        result = tdrv018WriteLE32(  hdl,
                                   TDRV018_RES_MEM_3,
                                   0x28,
                                   1,
                                   &intstat );
    }
    ...
}

```

```

    /* handle errors */
    return;
}

...
/* 
** Alternative Callback Function, using direct Register Access
*/
void callback_INPUTdirect(    TDRV018_HANDLE      hdl,
                               unsigned int       interruptOccurred,
                               void              *param,
                               TDRV018_STATUS    status )
{
    TDRV018_STATUS   result;
    USER_DATA_AREA   *pUsrData = (USER_DATA_AREA*)param;
    unsigned int      *pStatusReg;
    unsigned int      instat;

    if (status != TDRV018_OK)
    {
        /* handle error status */
    }

    /* calculate 32bit pointer to "Input Interrupt Status Register" */
    pStatusReg = (unsigned int*)(pUsrData->pRegSpace + 0x28);

    /* depending on the system architecture, the 32bit value must be
     ** adapted to the endianess (little or big endian).
     ** Use the provided API functions to handle this. */
    intstat = endian_le32(*pStatusReg);
    if (intstat != 0)
    {
        /* Acknowledge INPUT interrupt source. */
        *pStatusReg = endian_le32(intstat);

        /* handle the input interrupt */
    }

    return;
}

```

---

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified TDRV018_HANDLE is invalid.
TDRV018_ERR_INVALID_PARAMETER	Function or callback handle pointer is NULL.

Other returned error codes are system error conditions.

### 3.8.3 tdrv018InterruptUnregisterCallback

#### NAME

tdrv018InterruptUnregisterCallback – Unregister a User Callback Function

#### SYNOPSIS

```
TDRV018_STATUS tdrv018InterruptUnregisterCallback
(
    TDRV018_HANDLE     hdl
);
```

#### DESCRIPTION

This function unregisters a previously registered user callback function.

#### PARAMETERS

*hdl*

This value specifies the callback handle retrieved by a call to the corresponding register function.

#### EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE      callbackHdl;
TDRV018_STATUS      result;

/*
 **  Unregister a callback function
 */
result = tdrv018InterruptUnregisterCallback( callbackHdl );
if (result == TDRV018_OK)
{
    /* OK */
} else {
    /* handle error */
}
```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified callback handle is invalid.

Other returned error codes are system error conditions.

### 3.8.4 tdrv018InterruptConfig

#### NAME

tdrv018InterruptConfig – Configure the Interrupt handling method for User-FPGA implementations

#### SYNOPSIS

```
TDRV018_STATUS tdrv018InterruptConfig
(
    TDRV018_HANDLE      hdl,
    int                  ControlType,
    int                  ReadPciResource,
    int                  ReadAccessWidth,
    unsigned int          ReadOffset,
    unsigned int          ReadMask,
    int                  WritePciResource,
    int                  WriteAccessWidth,
    unsigned int          WriteOffset,
    unsigned int          WriteMask,
    unsigned int          WriteValue
);
```

#### DESCRIPTION

This function configures the interrupt handling method for User-FPGA specific implementations. Interrupt handling must be implemented on driver-level, so the driver must be configured properly to acknowledge an interrupt of the user-specific FPGA implementation. This function is only supported by User-FPGA devices.

**For User-FPGA devices, make sure to configure the interrupt handling before the User-FPGA implementation raises interrupts.**

#### PARAMETERS

*hdl*

This value specifies the callback handle retrieved by a call to the corresponding register-function.

#### *IntAckMethod*

This value specifies the interrupt acknowledgement method. Following values are possible:

<b>Value</b>	<b>Description</b>
TDRV018_INTACK_READ	Interrupt is cleared upon reading a status register.
TDRV018_INTACK_READCLEAR	Interrupt is cleared by writing the read register bits into the same register, using the same access width as for the read access.
TDRV018_INTACK_READWRITE	Interrupt is cleared upon writing a static value to a specific register.
TDRV018_INTACK_READWRITEMASK	Interrupt is cleared upon writing a static value to a specific register using a bit-mask, leaving specified original register bits unchanged.

#### *ReadPciResource*

This parameter specifies the desired PCI Memory resource to be used for reading the interrupt status. In general, a PCI target supports up to six base address registers. Following values are possible:

<b>Value</b>	<b>Description</b>
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

#### *ReadAccessWidth*

This parameter specifies the desired access width for reading the interrupt status. The driver always uses little-endian accesses. Following values are possible:

<b>Value</b>	<b>Description</b>
TDRV018_ACCESSWIDTH_8	A BYTE (8bit) register access is used.
TDRV018_ACCESSWIDTH_16	A WORD (16bit) register access is used.
TDRV018_ACCESSWIDTH_32	A DWORD (32bit) register access is used.

#### *ReadOffset*

This argument specifies the register offset within the PCI BAR space used for reading the interrupt status.

#### *ReadMask*

This argument specifies the bit-mask used for interrupt detection. This argument can be used to mask-out static register bits for proper support of PCI interrupt sharing.

#### *WritePciResource*

This parameter specifies the desired PCI Memory resource to be used for writing a static value. In general, a PCI target supports up to six base address registers. This parameter is not used for IntAckMethod READ and READCLEAR. Following values are possible:

Value	Description
TDRV018_RES_MEM_1	First found PCI Memory area.
TDRV018_RES_MEM_2	Second found PCI Memory area.
TDRV018_RES_MEM_3	Third found PCI Memory area.
TDRV018_RES_MEM_4	Fourth found PCI Memory area.
TDRV018_RES_MEM_5	Fifth found PCI Memory area.
TDRV018_RES_MEM_6	Sixth found PCI Memory area.

#### *WriteAccessWidth*

This parameter specifies the desired access width for writing the static value. The driver always uses little-endian accesses. This parameter is not used for IntAckMethod READ and READCLEAR. Following values are possible:

Value	Description
TDRV018_ACCESSWIDTH_8	A BYTE (8bit) register access is used.
TDRV018_ACCESSWIDTH_16	A WORD (16bit) register access is used.
TDRV018_ACCESSWIDTH_32	A DWORD (32bit) register access is used.

#### *WriteOffset*

This argument specifies the register offset within the PCI BAR space used for writing the static value. This parameter is not used for IntAckMethod READ and READCLEAR.

#### *WriteMask*

This argument specifies the bit-mask used for write access. This argument can be used to mask-out static register bits, changing only the desired ones. Specifying 0x00000000 is not valid. This parameter is not used for IntAckMethod READ and READCLEAR.

#### *WriteValue*

This argument specifies the static value to be used for writing. This parameter is not used for IntAckMethod READ and READCLEAR.

---

## EXAMPLE

```
#include "tdrv018api.h"

TDRV018_HANDLE      hdl;
TDRV018_STATUS      result;

/*
** Example 1:
** Configure the Interrupt Handler to use READCLEAR method
** - InterruptStatus Register in first PCI MemRes, at Offset 0x20
** - Use 32bit accesses
*/
result = tdrv018InterruptConfig( hdl,
                                TDRV018_INTACK_READCLEAR,
                                TDRV018_RES_MEM_1,                      // ReadPciResource
                                TDRV018_ACCESSWIDTH_32,                  // ReadAccessWidth
                                0x20,                                    // ReadOffset
                                0xFFFFFFFF,                            // check all register-bits
                                0, 0, 0, 0, 0, 0                         // do not use write-
                                                // parameters
);
if (result == TDRV018_OK)
{
    /* *OK */
} else {
    /* handle error */
}
```

...

```

/*
 ** Example 2:
 ** Configure the Interrupt Handler to use READWRITE method
 ** - InterruptStatus Register at PCI Memory Resource 1, Offset 0x20
 ** - Use 32bit accesses, check all register-bits
 ** - disable the Interrupt by writing 0x00000000 to PCI Memory Resource 1,
 **   Offset 0x24
 */
result = tdrv018InterruptConfig( hdl,
                                TDRV018_INTACK_READWRITE,
                                TDRV018_RES_MEM_1, // ReadPciResource
                                TDRV018_ACCESSWIDTH_32, // ReadAccessWidth
                                0x20, // ReadOffset
                                0xFFFFFFFF, // ReadMask
                                TDRV018_RES_MEM_1, // WritePciResource
                                TDRV018_ACCESSWIDTH_32, // WriteAccessWidth
                                0x24, // WriteOffset
                                0xFFFFFFFF, // WriteMask
                                0x00000000 // WriteValue
                               );
if (result == TDRV018_OK)
{
    /* *OK */
} else {
    /* handle error */
}

```

## RETURNS

On success, TDRV018\_OK is returned. In the case of an error, the appropriate error code is returned by the function.

## ERROR CODES

Error Code	Description
TDRV018_ERR_INVALID_HANDLE	The specified handle is invalid.
TDRV018_ERR_INVAL	The specified flags are invalid.
TDRV018_ERR_NOSYS	This function is not supported by the device.

## 4 Diagnostic

If the TDRV018 does not work properly it is helpful to get some status information from the driver respective kernel.

The Linux /proc file system provides information about kernel, resources, driver, devices, and so on. The following screen dumps displays information of a correct running TDRV018 driver (see also the proc man pages).

```
# lspci -v
...
04:02.0 Signal processing controller: TEWS Technologies GmbH Device 027a
(rev 01)
    Subsystem: TEWS Technologies GmbH Device 000c
    Flags: slow devsel, IRQ 17
    Memory at febffc00 (32-bit, non-prefetchable) [size=256]
    Memory at febff800 (32-bit, non-prefetchable) [size=256]
    Memory at feb80000 (32-bit, non-prefetchable) [size=256K]
    Kernel driver in use: TEWS Technologies - TDRV018 Device Driver
...
...

# cat /proc/devices
Character devices:
  1 mem
  2 pty
...
248 tdrv018drv
...

...

# cat /proc/iomem
00000000-0009f7ff : System RAM
...
feb00000-febfffff : PCI Bus 0000:04
    feb80000-febbffff : 0000:04:02.0
        feb80000-febbffff : TDRV018
    febfff800-febff8ff : 0000:04:02.0
        febfff800-febff8ff : TDRV018
    febffc00-febffcff : 0000:04:02.0
        febffc00-febffcff : TDRV018
...
...
```