

TDRV020-SW-95

QNX - Neutrino Device Driver

Reconfigurable FPGA

Version 1.0.x

User Manual

Issue 1.0.0

August 2018

TDRV020-SW-95

QNX - Neutrino Device Driver

Reconfigurable FPGA

Supported Modules:

TMPE623
TMPE627
TMPE633

This document contains information, which is proprietary to TEWS TECHNOLOGIES GmbH. Any reproduction without written permission is forbidden.

TEWS TECHNOLOGIES GmbH has made any effort to ensure that this manual is accurate and complete. However TEWS TECHNOLOGIES GmbH reserves the right to change the product described in this document at any time without notice.

TEWS TECHNOLOGIES GmbH is not liable for any damage arising out of the application or use of the device described herein.

©2018 by TEWS TECHNOLOGIES GmbH

Issue	Description	Date
1.0.0	First Issue	August 21, 2018

Table of Contents

1	INTRODUCTION.....	4
2	INSTALLATION.....	5
2.1	Building Executables on Native Systems	5
2.1.1	Build the Device Driver	5
2.1.2	Build the API Library.....	5
2.1.3	Build the Example Application	6
2.2	Building Executables with Momentics IDE (5.0).....	6
2.2.1	Build the Device Driver	6
2.2.2	Build the API Library.....	6
2.2.3	Build the Example Application	6
2.2.4	Integrate the Device Driver Files to a QNX-Image.....	7
2.3	Building Executables with Momentics IDE (7.0)	8
2.3.1	Build the Device Driver	8
2.3.2	Build the API Library.....	8
2.3.3	Build the Example Application	8
2.3.4	Integrate the Device Driver Files to a QNX-Image	9
2.4	Start the Driver Process	10
3	API DOCUMENTATION	11
3.1	General Functions.....	11
3.1.1	tdrv020Open	11
3.1.2	tdrv020Close.....	13
3.1.3	tdrv020GetPciInfo	15
3.2	Device Access Functions.....	17
3.2.1	tdrv020Read8	17
3.2.2	tdrv020ReadBE16	20
3.2.3	tdrv020ReadLE16.....	23
3.2.4	tdrv020ReadBE32	26
3.2.5	tdrv020ReadLE32.....	29
3.2.6	tdrv020Write8	32
3.2.7	tdrv020WriteBE16.....	35
3.2.8	tdrv020WriteLE16	38
3.2.9	tdrv020WriteBE32.....	41
3.2.10	tdrv020WriteLE32	44
3.3	Resource Mapping Functions.....	47
3.3.1	tdrv020PciResourceMap	47
3.3.2	tdrv020PciResourceUnmap.....	49
3.4	Interrupt Functions	51
3.4.1	tdrv020InterruptConfig	51
3.4.2	tdrv020InterruptWait	56
3.4.3	tdrv020InterruptRegisterCallbackThread.....	59
3.4.4	tdrv020InterruptUnregisterCallback.....	64
3.5	Endian Conversion Functions	66
3.5.1	endian_be16	66
3.5.2	endian_le16	67
3.5.3	endian_be32	68
3.5.4	endian_le32	69

1 Introduction

The TDRV020-SW-95 QNX-Neutrino device driver allows the operation of the supported CAN Bus devices on QNX-Neutrino operating systems.

The TDRV020 device driver is basically implemented as a user installable Resource Manager. The standard file (I/O) functions (open, close and devctl) provide the basic interface for opening and closing a file descriptor and for performing device I/O and control operations.

The TDRV020-SW-95 device driver was designed to provide register access to an FPGA application.

The TDRV020-SW-95 device driver supports the following features:

- Read/write access to FPGA registers (8,16,32-bit)
- Resource allocation for supported modules
- Wait for interrupts
- Register Callback functions for interrupt handling
- Driver functions are thread-safe as long as unique handles are used.

The TDRV020-SW-95 device driver supports the modules listed below:

TMPE623	Reconfigurable FPGA with Digital I/O	PCIe Mini Card
TMPE627	Reconfigurable FPGA with AD/DA and Digital I/O	PCIe Mini Card
TMPE633	Reconfigurable FPGA with Digital I/O	PCIe Mini Card

In this document all supported modules and devices will be called TDRV020. Specials for certain devices will be advised.

To get more information about the features and use of TDRV020 devices it is recommended to read the manuals listed below.

Corresponding Hardware User manual

Related FPGA Development Kit documentation

2 Installation

Following files are located in the directory TDRV020-SW-95 on the distribution media:

TDRV020-SW-95-SRC.tar.gz	GZIP compressed archive with driver source code
TDRV020-SW-95-1.0.0.pdf	This manual in PDF format
ChangeLog.txt	Release history
Release.txt	Information about the Device Driver Release

The GZIP compressed archive TDRV020-SW-95-SRC.tar.gz contains the following files and directories:

Directory path 'tdrv020':

/driver/tdrv020.c	Driver source code
/driver/tdrv020.h	Definitions and data structures for driver and application
/driver/tdrv020def.h	Device driver include
/driver/node.c	Queue management source code
/driver/node.h	Queue management definitions
/driver/nto/*	Driver Build path
/api/example.c	API Library
/api/nto/*	API Library Build path
/example/example.c	Example application
/example/nto/*	Example application Build path

2.1 Building Executables on Native Systems

For installation copy the tar-archive into the /usr/src directory and unpack it (e.g. `tar -xzvf TDRV020-SW-95-SRC.tar.gz`). After that the necessary directory structure for the automatic build and the source files are available underneath the new directory called `tdrv020`.

It is absolutely important to extract the TDRV020 tar archive in the /usr/src directory. Otherwise the automatic build with make will fail.

2.1.1 Build the Device Driver

Change to the /usr/src/tdrv020/driver directory

Execute the Makefile:

```
# make install
```

After successful completion the driver binary (`tdrv020`) will be installed in the /bin directory.

2.1.2 Build the API Library

Change to the /usr/src/tdrv020/api directory

Execute the Makefile:

```
# make install
```

After successful completion the API Library will be installed and is available for later usage.

2.1.3 Build the Example Application

Change to the /usr/src/tdrv020/example directory

Execute the Makefile:

```
# make install
```

After successful completion the example binary (*tdrv020exa*) will be installed in the /bin directory.

2.2 Building Executables with Momentics IDE (5.0)

This chapter gives just a simple description how to build the drivers with the Momentics IDE (5.0), for more detailed information please refer to the appropriate documentation.

For installation unpack the tar-archive into the desired working directory.

After that the necessary directory structure for the automatic build and the source files are available beneath the new directory called *tdrv020*.

2.2.1 Build the Device Driver

Create a new project ("Makefile Project with Existing Code") in your workspace:

- Select a "Project Name" (e.g. TDRV020)
- Select the path "tdrv020\driver" in the working directory as "Existing Code Location"
- Select the "Toolchain for Indexer Settings" (e.g. "QNX Multi-toolchain")

Now the device driver can be built by "Building the Project".

After successful completion the IDE shows a "Binaries"-path containing the built binary of tdrv020 device driver. (e.g. "tdrv020 – [x86/le]")

2.2.2 Build the API Library

Create a new project ("Makefile Project with Existing Code") in your workspace:

- Select a "Project Name" (e.g. TDRV020-API)
- Select the path "tdrv020\api" in the working directory as "Existing Code Location"
- Select the "Toolchain for Indexer Settings" (e.g. "QNX Multi-toolchain")

Now the API Library can be built by "Building the Project".

2.2.3 Build the Example Application

Create a new project ("Makefile Project with Existing Code") in your workspace:

- Select a "Project Name" (e.g. TDRV020-Example)
- Select the path "tdrv020\example" in the working directory as "Existing Code Location"
- Select the "Toolchain for Indexer Settings" (e.g. "QNX Multi-toolchain")
- Copy the TDRV020 API Library binary file (libtdrv020api.a) into the local QNX library path

Now the example can be built by "Building the Project".

After successful completion the IDE shows a "Binaries"-path containing the built binary of tdrv020 example application. (e.g. "tdrv020exa – [x86/le]")

2.2.4 Integrate the Device Driver Files to a QNX-Image

To add the device driver file and the example application file to a QNX-Image, just a few steps are necessary.

Copy the desired binary files of the device driver and example project into "sbin" beneath the "install"-path of the target project using the Momentics-IDE.

Add the filenames of the added files into the build-file (e.g. "x86-generic.build") in "images". For example the filenames (e.g. tdrv020, tdrv020exa) can be inserted behind the serial driver names (insert each filename in a separate line).

After a rebuild of the QNX-Image, the driver files will be available on the disk and can be used after booting.

2.3 Building Executables with Momentics IDE (7.0)

This chapter gives just a simple description how to build the drivers with the Momentics IDE (7.0), for more detailed information please refer to the appropriate documentation.

For installation unpack the tar-archive into the desired working directory.

After that the necessary directory structure for the automatic build and the source files are available beneath the new directory called *tdrv020*.

2.3.1 Build the Device Driver

Create a new project ("Makefile Project with Existing Code") in your workspace:

- Select a "Project Name" (e.g. TDRV020)
- Select the path "tdrv020\driver" in the working directory as "Existing Code Location"
- Select the "Toolchain for Indexer Settings" (e.g. "QNX Multi-toolchain")

Now we have to specify the name of the driver executable and additional libraries needed for the driver. Open the projects properties (Alt+Enter), select C/C++ Build→Environment and add the following environment variables and values to the necessary configurations:

- NAME = tdrv020
- LIBS = pci

Now the device driver can be built by "Building the Project".

After successful completion the IDE shows a "Binaries"-path containing the built binaries of tdrv020 device driver of the enabled configurations (e.g. "tdrv020 – [x86/le]" and "tdrv020 – [x86_64/le]").

2.3.2 Build the API Library

Create a new project ("Makefile Project with Existing Code") in your workspace:

- Select a "Project Name" (e.g. TDRV020-API)
- Select the path "tdrv020\api" in the working directory as "Existing Code Location"
- Select the "Toolchain for Indexer Settings" (e.g. "QNX Multi-toolchain")

Now we have to specify the name of the driver API library. Open the projects properties (Alt+Enter), select C/C++ Build→Environment and add the following environment variables and values to the necessary configurations:

- NAME = tdrv020api

Now the API Library can be built by "Building the Project".

2.3.3 Build the Example Application

Create a new project ("Makefile Project with Existing Code") in your workspace:

- Select a "Project Name" (e.g. TDRV020-Example)
- Select the path "tdrv020\example" in the working directory as "Existing Code Location"
- Select the "Toolchain for Indexer Settings" (e.g. "QNX Multi-toolchain")
- Copy the TDRV020 API Library binary file (libtdrv020api.a) into the local QNX library path

Now we have to specify the name of the driver example executable. Open the projects properties (Alt+Enter), select C/C++ Build→Environment and add the following environment variables and values to the necessary configurations:

- NAME = tdrv020exa
- LIBS = tdrv020api

Now the example can be built by “Building the Project”.

After successful completion the IDE shows a “Binaries”-path containing the built binaries of tdrv020 example application of the enabled configurations. (e.g. “tdrv020exa – [x86/le]” and “tdrv020exa – [x86_64/le]”)

2.3.4 Integrate the Device Driver Files to a QNX-Image

To add the device driver file and the example application file to a QNX-Image, just a few steps are necessary.

Copy the desired binary files of the device driver and example project into “sbin” beneath the “install”-path of the target project using the Momentics-IDE.

Add the filenames of the added files into the build-file (e.g. “x86-generic.build”) in “images”. For example the filenames (e.g. tdrv020, tdrv020exa) can be inserted behind the serial driver names (insert each filename in a separate line).

After a rebuild of the QNX-Image, the driver files will be available on the disk and can be used after booting.

2.4 Start the Driver Process

To start the TDRV020 device driver, you have to enter the process name with optional parameter from the command shell or in the startup script.

```
tdrv020 [-v] &
```

The TDRV020 Resource Manager creates one device for each supported module, and registers the created devices in the Neutrino's pathname space under following names.

```
/dev/tdrv020_0  
/dev/tdrv020_1  
...  
/dev/tdrv020_x
```

The pathname must be used in the application program to open a path to the desired TDRV020 device.

For debugging, you can start the TDRV020 Resource Manager with the `-v` option. Now the Resource Manager will print versatile information about TDRV020 configuration and command execution on the terminal window.

Make sure that only one instance of the device driver process is started.

3 API Documentation

3.1 General Functions

3.1.1 tdrv020Open

NAME

tdrv020Open – open a device.

SYNOPSIS

```
TDRV020_HANDLE tdrv020Open
(
    char      *DeviceName
)
```

DESCRIPTION

Before I/O can be performed to a device, a device handle must be opened by a call to this function.

The tdrv020Open function can be called multiple times (e.g. in different tasks).

PARAMETERS

DeviceName

This parameter points to a null-terminated string that specifies the name of the device. The first TDRV020 device is named “/dev/tdrv020_0” the second device is named “/dev/tdrv020_1” and so on.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE hdl;

/*
 ** open the specified device
 */
hdl = tdrv020Open( "/dev/tdrv020_0" );
if (hdl == NULL)
{
    /* handle open error */
}
```

RETURNS

A device handle, or NULL if the function fails. An error code will be stored in *errno*.

ERROR CODES

The error codes are stored in *errno*.

The error code is a standard error code set by the I/O system.

3.1.2 tdrv020Close

NAME

tdrv020Close – close a device.

SYNOPSIS

```
TDRV020_STATUS tdrv020Close
(
    TDRV020_HANDLE     hdl
)
```

DESCRIPTION

This function closes a previously opened device.

PARAMETERS

hdl

This value specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE     hdl;
TDRV020_STATUS     result;

/*
 ** close the device
 */
result = tdrv020Close(hdl);
if (result != TDRV020_OK)
{
    /* handle close error */
}
```

RETURNS

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid

3.1.3 tdrv020GetPciInfo

NAME

tdrv020GetPciInfo – get information of the module PCI header

SYNOPSIS

```
TDRV020_STATUS tdrv020GetPciInfo
(
    TDRV020_HANDLE          hdl,
    TDRV020_PCIINFO_BUF     *pPciInfoBuf
)
```

DESCRIPTION

This function returns information of the module PCI header in the provided data buffer.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pPciInfoBuf

This argument is a pointer to the structure TDRV020_PCIINFO_BUF that receives information of the module PCI header.

```
typedef struct
{
    unsigned short    vendorId;
    unsigned short    devicelId;
    unsigned short    subSystemId;
    unsigned short    subSystemVendorId;
    int               pciBusNo;
    int               pciDevNo;
    int               pciFuncNo;
} TDRV020_PCIINFO_BUF;
```

vendorId

PCI module vendor ID.

devicelD

PCI module device ID

subSystemId
 PCI module sub system ID

subSystemVendorId
 PCI module sub system vendor ID

pciBusNo
 Number of the PCI bus, where the module resides.

pciDevNo
 PCI device number

pciFuncNo
 PCI function number

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE          hdl;
TDRV020_STATUS           result;
TDRV020_PCIINFO_BUF     pciInfoBuf

/*
 ** get module PCI information
 */
result = tdrv020GetPciInfo(hdl, &pciInfoBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid

3.2 Device Access Functions

3.2.1 tdrv020Read8

NAME

tdrv020Read8 – read 8-bit values from PCI BAR space

SYNOPSIS

```
TDRV020_STATUS tdrv020Read8
(
    TDRV020_HANDLE      hdl,
    int                  pciResource,
    int                  offset,
    int                  numItems,
    unsigned char        *pData
)
```

DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using single byte (8-bit) accesses.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (8-bit) to read.

pData

This argument is a pointer to an unsigned char buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

#define NUM_ITEMS 256

TDRV020_HANDLE hdl;
TDRV020_STATUS result;
int offset;
unsigned char dataBuf[NUM_ITEMS];

offset = 0x0000;
/*
 ** read 256 Bytes from the User FPGA Register Area
 */
result = tdrv020Read8(hdl, TDRV020_RES_MEM_1, offset, NUM_ITEMS, dataBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.2 tdrv020ReadBE16

NAME

tdrv020ReadBE16 – read 16-bit values from PCI BAR space in big-endian order

SYNOPSIS

```
TDRV020_STATUS tdrv020ReadBE16
```

```
(  
    TDRV020_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned short      *pData  
)
```

DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using 16-bit accesses. The values are returned as big-endian values that mean on Intel x86 architectures the multi-byte data will be byte-swapped.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (16-bit) to read.

pData

This argument is a pointer to an unsigned short buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

#define NUM_ITEMS 128

TDRV020_HANDLE      hdl;
TDRV020_STATUS      result;
int                 offset;
unsigned short       dataBuf[NUM_ITEMS];

offset = 0x0000;
/*
 ** read 256 Bytes from the User FPGA Register Area
 */
result = tdrv020ReadBE16(hdl, TDRV020_RES_MEM_1, offset, NUM_ITEMS,
                         dataBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.3 tdrv020ReadLE16

NAME

tdrv020ReadLE16 – read 16-bit values from PCI BAR space in little-endian order

SYNOPSIS

```
TDRV020_STATUS tdrv020ReadLE16
```

```
(  
    TDRV020_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned short      *pData  
)
```

DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using 16-bit accesses. The values are returned as little-endian values that means on Intel x86 architectures the multi-byte data will not be byte-swapped.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (16-bit) to read.

pData

This argument is a pointer to an unsigned short buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

#define NUM_ITEMS 128

TDRV020_HANDLE      hdl;
TDRV020_STATUS      result;
int                 offset;
unsigned short       dataBuf[NUM_ITEMS];

offset = 0x0000;
/*
** read 256 Bytes from the User FPGA Register Area
*/
result = tdrv020ReadLE16(hdl, TDRV020_RES_MEM_1, offset, NUM_ITEMS,
                         dataBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.4 tdrv020ReadBE32

NAME

tdrv020ReadBE32 – read 32-bit values from PCI BAR space in big-endian order

SYNOPSIS

```
TDRV020_STATUS tdrv020ReadBE32
```

```
(  
    TDRV020_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned int        *pData  
)
```

DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using 32-bit accesses. The values are returned as big-endian values that means on Intel x86 architectures the multi-byte data will be byte-swapped.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (32-bit) to read.

pData

This argument is a pointer to an unsigned int buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

#define NUM_ITEMS 1

TDRV020_HANDLE      hdl;
TDRV020_STATUS      result;
int                  offset;
unsigned int         dataBuf[NUM_ITEMS];

offset = 0;
/*
** read Digital Input Register of FPGA Example Design
*/
result = tdrv020ReadBE32(hdl, TDRV020_RES_MEM_1, offset, NUM_ITEMS,
                         dataBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.5 tdrv020ReadLE32

NAME

tdrv020ReadLE32 – read 32-bit values from PCI BAR space in little-endian order

SYNOPSIS

```
TDRV020_STATUS tdrv020ReadLE32
```

```
(  
    TDRV020_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned int        *pData  
)
```

DESCRIPTION

This function reads the specified number of items from the PCI BAR space by using 32-bit accesses. The values are returned as little-endian values that means on Intel x86 architectures the multi-byte data will not be byte-swapped.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (32-bit) to read.

pData

This argument is a pointer to an unsigned int buffer which will be filled with the specified number of items from the PCI BAR space. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

#define NUM_ITEMS 1

TDRV020_HANDLE      hdl;
TDRV020_STATUS      result;
int                  offset;
unsigned int         dataBuf[NUM_ITEMS];

offset = 0;
/*
** read Digital Input Register of FPGA Example Design
*/
result = tdrv020ReadLE32(hdl, TDRV020_RES_MEM_1, offset, NUM_ITEMS,
                         dataBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.6 tdrv020Write8

NAME

tdrv020Write8 – write 8-bit values to the PCI BAR space

SYNOPSIS

```
TDRV020_STATUS tdrv020Write8
(
    TDRV020_HANDLE      hdl,
    int                 pciResource,
    int                 offset,
    int                 numItems,
    unsigned char       *pData
)
```

DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using single byte (8-bit) accesses.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (8-bit) to write.

pData

This argument is a pointer to an unsigned char buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

#define NUM_ITEMS 4

TDRV020_HANDLE      hdl;
TDRV020_STATUS      result;
int                  offset;
unsigned char        dataBuf[NUM_ITEMS];

dataBuf[0] = 0xAA;
dataBuf[1] = 0x55;
...
offset = 0x00;

/*
 ** write 4 bytes to a 32bit Scratchpad Register
 */
result = tdrv020Write8(hdl, TDRV020_RES_MEM_1, offset, NUM_ITEMS, dataBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.7 tdrv020WriteBE16

NAME

tdrv020WriteBE16 – write 16-bit values to the PCI BAR space big-endian order

SYNOPSIS

```
TDRV020_STATUS tdrv020WriteBE16
```

```
(  
    TDRV020_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned short      *pData  
)
```

DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using 16-bit accesses.

The values are written in big-endian order that means on Intel x86 architectures the multi-byte data will be byte-swapped.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (16-bit) to write.

pData

This argument is a pointer to an unsigned short buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

#define NUM_ITEMS 2

TDRV020_HANDLE hdl;
TDRV020_STATUS result;
int offset;
unsigned short dataBuf[NUM_ITEMS];

dataBuf[0] = 0xAA55;
dataBuf[1] = 0x55AA;
...

offset = 0xF8;
/*
** write 2 datawords to a 32bit Scratchpad Register
*/
result = tdrv020WriteBE16(hdl, TDRV020_RES_MEM_1, offset, NUM_ITEMS,
                           dataBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.8 tdrv020WriteLE16

NAME

tdrv020WriteLE16 – write 16-bit values to the PCI BAR space in little-endian order

SYNOPSIS

```
TDRV020_STATUS tdrv020WriteLE16
```

```
(  
    TDRV020_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned short      *pData  
)
```

DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using 16-bit accesses.

The values are written in little-endian order that means on Intel x86 architectures the multi-byte data will not be byte-swapped.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (16-bit) to write.

pData

This argument is a pointer to an unsigned short buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

#define NUM_ITEMS 2

TDRV020_HANDLE hdl;
TDRV020_STATUS result;
int offset;
unsigned short dataBuf[NUM_ITEMS];

dataBuf[0] = 0xAA55;
dataBuf[1] = 0x55AA;
...

offset = 0xF8;
/*
** write 2 data words to a 32bit Scratchpad Register
*/
result = tdrv020WriteLE16(hdl, TDRV020_RES_MEM_1, offset, NUM_ITEMS,
                           dataBuf);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.9 tdrv020WriteBE32

NAME

tdrv020WriteBE32 – write 32-bit values to the PCI BAR space big-endian order

SYNOPSIS

```
TDRV020_STATUS tdrv020WriteBE32
```

```
(  
    TDRV020_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned int        *pData  
)
```

DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using 32-bit accesses.

The values are written in big-endian order that means on Intel x86 architectures the multi-byte data will be byte-swapped.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (32-bit) to write.

pData

This argument is a pointer to an unsigned int buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE      hdl;
TDRV020_STATUS      result;
int                  offset;
unsigned int         data;

data     = 0x12345678;
offset   = 0xF8;
/* Write Test data into a 32bit Scratchpad Register */
result = tdrv020WriteBE32(hdl, TDRV020_RES_MEM_1, offset, 1, &data);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.2.10 tdrv020WriteLE32

NAME

tdrv020WriteLE32 – write 32-bit values to the PCI BAR space in little-endian order

SYNOPSIS

```
TDRV020_STATUS tdrv020WriteLE32
```

```
(  
    TDRV020_HANDLE     hdl,  
    int                 pciResource,  
    int                 offset,  
    int                 numItems,  
    unsigned int        *pData  
)
```

DESCRIPTION

This function writes the specified number of items to the PCI BAR space by using 32-bit accesses.

The values are written in little-endian order that means on Intel x86 architectures the multi-byte data will not be byte-swapped.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

offset

This argument specifies the start offset within the PCI BAR space.

numItems

This argument specifies the number of items (32-bit) to write.

pData

This argument is a pointer to an unsigned int buffer with the data items to write. The allocated space must be large enough to hold the specified amount of data.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE      hdl;
TDRV020_STATUS      result;
int                  offset;
unsigned int         data;

data     = 0x12345678;
offset   = 0xF8;
/* Write Test data into a 32bit Scratchpad Register */
result = tdrv020WriteLE32(hdl, TDRV020_RES_MEM_1, offset, 1, &data);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	The specified access range exceeds PCI BAR limits
TDRV020_ERR_ACCESS	The specified PCI resource is not available

3.3 Resource Mapping Functions

3.3.1 tdrv020PciResourceMap

NAME

tdrv020PciResourceMap – map a PCI resource directly into the process context

SYNOPSIS

```
TDRV020_STATUS tdrv020PciResourceMap
(
    TDRV020_HANDLE      hdl,
    int                 pciResource,
    unsigned char       **pPtr,
    unsigned int         *pSize
)
```

DESCRIPTION

This function maps the specified PCI resource of the hardware module directly into the process context. The retrieved pointer can be used for direct non-cached register access.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pciResource

This parameter specifies the desired PCI Memory resource to be used for this access. In general, a PCI target (PCIe bridge) supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

The Base Address Register usage is programmable and can be changed by modifying the PCIe bridge configuration. Therefore the following table is just an example how the PCI Base Address Registers could be used.

PCI Base Address Register	PCI Address-Type	TDRV020 Resource
0	MEM	TDRV020_RES_MEM_1
1	MEM (<i>not used</i>)	TDRV020_RES_MEM_2
2	MEM (<i>not used</i>)	TDRV020_RES_MEM_3

pPtr

This argument is a pointer to an unsigned char pointer that receives the start address of the mapped PCI resource.

pSize

This argument returns the size of the mapped PCI resource in bytes.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE      hdl;
TDRV020_STATUS       result;
unsigned char        *pReg;
unsigned int          size;

/*
 ** map first memory PCI resource
 */
result = tdrv020PciResourceMap(hdl, TDRV020_RES_MEM_1, &pReg, &size);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_ACCESS	Specified PCI resource not available
TDRV020_ERR_NOMEM	Unable to allocate memory

3.3.2 tdrv020PciResourceUnmap

NAME

tdrv020PciResourceUnmap – unmap a previously mapped PCI resource

SYNOPSIS

```
TDRV020_STATUS tdrv020PciResourceUnmap
(
    TDRV020_HANDLE      hdl,
    unsigned char        *pPtr
)
```

DESCRIPTION

This function unmaps a previously mapped PCI resource, freeing the system resources used for this mapping.

PARAMETERS

hdl

This argument specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

pPtr

This argument is a pointer to an unsigned char pointer that represents the start address of the previously mapped PCI resource. This pointer must have been received from the corresponding mapping function.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE      hdl;
TDRV020_STATUS       result;
unsigned char        *pReg;

/*
 ** unmap a previously mapped PCI resource
 */
result = tdrv020PciResourceUnmap(hdl, pReg);

if (result != TDRV020_OK)
{
    /* handle error */
}
```

RETURN VALUE

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified device handle is invalid
TDRV020_ERR_INVAL	Invalid pointer specified

3.4 Interrupt Functions

3.4.1 tdrv020InterruptConfig

NAME

tdrv020InterruptConfig – Configure the Interrupt handling method for User-FPGA implementations

SYNOPSIS

```
TDRV020_STATUS tdrv020InterruptConfig
(
    TDRV020_HANDLE      hdl,
    int                 ControlType,
    int                 ReadPciResource,
    int                 ReadAccessWidth,
    unsigned int         ReadOffset,
    unsigned int         ReadMask,
    int                 WritePciResource,
    int                 WriteAccessWidth,
    unsigned int         WriteOffset,
    unsigned int         WriteMask,
    unsigned int         WriteValue
)
```

DESCRIPTION

This function configures the interrupt handling method for User-FPGA specific implementations. Interrupt handling must be implemented on driver-level, so the driver must be configured properly to acknowledge an interrupt of the user-specific FPGA implementation.

Make sure to configure the interrupt handling before the User-FPGA implementation raises interrupts.

PARAMETERS

hdl

This value specifies the callback handle retrieved by a call to the corresponding register-function.

IntAckMethod

This value specifies the interrupt acknowledgement method. Following values are possible:

Value	Description
TDRV020_INTACK_READ	Interrupt is cleared upon reading a status register.
TDRV020_INTACK_READCLEAR	Interrupt is cleared by writing the read register bits into the same register, using the same access width as for the read access.
TDRV020_INTACK_READWRITE	Interrupt is cleared upon writing a static value to a specific register.
TDRV020_INTACK_READWRITEMASK	Interrupt is cleared upon writing a static value to a specific register using a bit-mask, leaving specified original register bits unchanged.

ReadPciResource

This parameter specifies the desired PCI Memory resource to be used for reading the interrupt status. In general, a PCI target supports up to six base address registers. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

ReadAccessWidth

This parameter specifies the desired access width for reading the interrupt status. The driver always uses little-endian accesses. Following values are possible:

Value	Description
TDRV020_ACCESSWIDTH_8	A BYTE (8bit) register access is used.
TDRV020_ACCESSWIDTH_16	A WORD (16bit) register access is used.
TDRV020_ACCESSWIDTH_32	A DWORD (32bit) register access is used.

ReadOffset

This argument specifies the register offset within the PCI BAR space used for reading the interrupt status.

ReadMask

This argument specifies the bit-mask used for interrupt detection. This argument can be used to mask-out static register bits for proper support of PCI interrupt sharing.

WritePciResource

This parameter specifies the desired PCI Memory resource to be used for writing a static value. In general, a PCI target supports up to six base address registers. This parameter is not used for IntAckMethod READ and READCLEAR. Following values are possible:

Value	Description
TDRV020_RES_MEM_1	First found PCI Memory area.
TDRV020_RES_MEM_2	Second found PCI Memory area.
TDRV020_RES_MEM_3	Third found PCI Memory area.
TDRV020_RES_MEM_4	Fourth found PCI Memory area.
TDRV020_RES_MEM_5	Fifth found PCI Memory area.
TDRV020_RES_MEM_6	Sixth found PCI Memory area.

WriteAccessWidth

This parameter specifies the desired access width for writing the static value. The driver always uses little-endian accesses. This parameter is not used for IntAckMethod READ and READCLEAR. Following values are possible:

Value	Description
TDRV020_ACCESSWIDTH_8	A BYTE (8bit) register access is used.
TDRV020_ACCESSWIDTH_16	A WORD (16bit) register access is used.
TDRV020_ACCESSWIDTH_32	A DWORD (32bit) register access is used.

WriteOffset

This argument specifies the register offset within the PCI BAR space used for writing the static value. This parameter is not used for IntAckMethod READ and READCLEAR.

WriteMask

This argument specifies the bit-mask used for write access. This argument can be used to mask-out static register bits, changing only the desired ones. Specifying 0x00000000 is not valid. This parameter is not used for IntAckMethod READ and READCLEAR.

WriteValue

This argument specifies the static value to be used for writing. This parameter is not used for IntAckMethod READ and READCLEAR.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE          hdl;
TDRV020_STATUS          result;

/*
** Example 1:
** Configure the Interrupt Handler to use READCLEAR method
** - InterruptStatus Register in first PCI MemRes, at Offset 0x20
** - Use 32bit accesses
*/
result = tdrv020InterruptConfig( hdl,
                                TDRV020_INTACK_READCLEAR,
                                TDRV020_RES_MEM_1,           // ReadPciResource
                                TDRV020_ACCESSWIDTH_32,      // ReadAccessWidth
                                0x20,                        // ReadOffset
                                0xFFFFFFF,                   // check all register-bits
                                0, 0, 0, 0, 0                // do not use write-
                                // parameters
);
if (result == TDRV020_OK)
{
    /*OK */
} else {
    /* handle error */
}
```

...

```

/*
** Example 2:
** Configure the Interrupt Handler to use READWRITE method
** - InterruptStatus Register at PCI Memory Resource 1, Offset 0x20
** - Use 32bit accesses, check all register-bits
** - disable the Interrupt by writing 0x00000000 to PCI Memory Resource 1,
**     Offset 0x24
*/
result = tdrv020InterruptConfig( hdl,
                                TDRV020_INTACK_READWRITE,
                                TDRV020_RES_MEM_1,           // ReadPciResource
                                TDRV020_ACCESSWIDTH_32,      // ReadAccessWidth
                                0x20,                        // ReadOffset
                                0xFFFFFFFF,                 // ReadMask
                                TDRV020_RES_MEM_1,           // WritePciResource
                                TDRV020_ACCESSWIDTH_32,      // WriteAccessWidth
                                0x24,                        // WriteOffset
                                0xFFFFFFFF,                 // WriteMask
                                0x00000000                  // WriteValue
                               );
if (result == TDRV020_OK)
{
    /*OK */
} else {
    /* handle error */
}

```

RETURNS

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified handle is invalid.
TDRV020_ERR_INVAL	The specified flags are invalid.
TDRV020_ERR_NOSYS	This function is not supported by the device.

3.4.2 tdrv020InterruptWait

NAME

tdrv020InterruptWait – Wait for incoming Local Interrupt Source

SYNOPSIS

```
TDRV020_STATUS tdrv020InterruptWait
(
    TDRV020_HANDLE      hdl,
    unsigned int         interruptMask,
    unsigned int         *pInterruptOccurred,
    int                 timeout
)
```

DESCRIPTION

This function enables the specified local interrupt sources, and waits for interrupts on the specified local interrupt sources. After an interrupt has arrived, the corresponding occurred local interrupt source is disabled inside the Infrastructure Module (IM). Multiple functions may wait for the same interrupt source to occur.

The delay between an incoming interrupt and the return of the described function is system-dependent, and is most likely several microseconds.

PARAMETERS

hdl

This value specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

interruptMask

This parameter specifies specific interrupt bits to wait for. The interrupt bits correspond to the Infrastructure Module's "Interrupt Pending Register" bits described in the FDK user manual. Please refer to the hardware user manual for further information on the possible interrupt bits. The function returns if at least one of the specified interrupt sources is detected.

pInterruptOccurred

If at least one of the specified interrupt sources occurs, the value is returned through this pointer. The interrupt bits correspond to the Infrastructure Module's "Interrupt Pending Register" bits described in the FDK user manual. Please refer to the hardware user manual for further information on the possible interrupt bits.

timeout

This value specifies the timeout in milliseconds the function will wait for the interrupt to arrive. The granularity depends on the operating system. To wait indefinitely, specify -1 as timeout parameter.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE      hdl;
TDRV020_STATUS       result;
unsigned int          interruptMask;
unsigned int          interruptOccurred;

/*
** Wait at least 5 seconds for incoming interrupts on UINTP0 and/or UINTP1
*/
interruptMask = (1 << 17) | (1 << 16);
result = tdrv020InterruptWait(    hdl,
                                interruptMask,
                                &interruptOccurred,
                                5000 );
if (result == TDRV020_OK)
{
    /* Interrupt arrived.                                     */
    /* Now acknowledge interrupt source in FPGA logic     */
    /* to clear the Local Interrupt Source.                 */
    /* Use tdrv020Read and tdrv020Write functions for     */
    /* register access.                                     */
} else {
    /* handle error */
}
```

RETURNS

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified TDRV020_HANDLE is invalid.
TDRV020_ERR_TIMEOUT	The specified timeout occurred.

3.4.3 tdrv020InterruptRegisterCallbackThread

NAME

tdrv020InterruptRegisterCallbackThread – Register a User Callback Function for Interrupt Handling

SYNOPSIS

```
TDRV020_STATUS tdrv020InterruptRegisterCallbackThread  
(  
    TDRV020_HANDLE     hdl,  
    int                threadPriority,  
    int                stackSize,  
    unsigned int        interruptMask,  
    FUNCINTCALLBACK   callbackFunction,  
    void*              *funcparam,  
    TDRV020_HANDLE     *pCallbackHandle  
)
```

DESCRIPTION

This function registers a user callback function which is executed after detection of the specified interrupt source. It is possible to register multiple callback functions to one or a set (bit mask) of interrupt sources.

The callback function is executed in a thread context, so using TDRV020 device driver functions and system functions is allowed. The callback function should be kept as short as possible. The specified callback function is executed with the occurred interrupt bits and the specified function parameter as function arguments. Additionally, a status value is passed to the callback function, which reflects the result of the involved API functions.

The delay between an incoming interrupt and the execution of the callback function is system-dependent, and is most likely several microseconds.

PARAMETERS

hdl

This value specifies the device handle to the hardware module retrieved by a call to the corresponding open-function.

threadPriority

This parameter specifies the priority to be used for the callback thread. Possible values are:

Value	Description
TDRV020_PRIORITY_NORMAL	Normal Priority (THREAD_PRIORITY_NORMAL)
TDRV020_PRIORITY_HIGH	High Priority (THREAD_PRIORITY_HIGHEST)
TDRV020_PRIORITY_LOW	Low Priority (THREAD_PRIORITY_LOWEST)

Other values might be possible.

stackSize

This parameter specifies the stack size to be used for the callback thread. The value is specified in bytes.

interruptMask

This parameter specifies specific interrupt bits to wait for. The interrupt bits correspond to the Infrastructure Module's "Interrupt Pending Register" bits described in the FDK user manual. Please refer to the hardware user manual for further information on the possible interrupt bits. The callback function is executed if at least one of the specified interrupt sources occurred.

callbackFunction

This parameter is a function pointer to the user callback function. The callback function pointer is defined as follows:

```
typedef void(*FUNCINTCALLBACK)( TDRV020_HANDLE hdl,
                                unsigned int interruptOccurred,
                                void *param,
                                TDRV020_STATUS status );
```

hdl

This parameter specifies a device handle which can be used for hardware access or other API functions by the callback function.

interruptOccurred

This parameter is a 32bit value reflecting the occurred interrupts. It is useful if the callback function handles multiple interrupt sources. The interrupt bits correspond to the Infrastructure Module's "Interrupt Pending Register" bits described in the FDK user manual. Please refer to the hardware user manual for further information on the possible interrupt bits.

param

This parameter is the user-specified *funcparam* value (see below) which has been specified on callback registration. This value can be used to pass a pointer to a specific control structure, to supply the callback function with specific information.

status

This parameter hands over interrupt callback status information. The callback function needs to check this parameter. If the specified interrupt source has occurred properly, and no errors were detected, this parameter is TDRV020_OK. If this parameter differs from TDRV020_OK, an internal error has been detected and the callback handling is stopped. The callback function must implement an appropriate error handling.

funcparam

This value specifies a user parameter, which will be handed over to the callback function on execution. This parameter can be used to pass a pointer to a specific control structure used by the callback function.

pCallbackHandle

This value specifies a pointer to a handle, where the callback handle will be returned. This callback handle must be used to unregister a callback function.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE      hdl;
TDRV020_STATUS      result;
unsigned int         interruptMask;
USER_DATA_AREA       userDataArea;
TDRV020_HANDLE      callbackHandle;

/* forward declaration of callback functions */
void callback_TIMER0(    TDRV020_HANDLE      hdl,
                           unsigned int     interruptOccurred,
                           void           *param,
                           TDRV020_STATUS status);

/*
 ** Register callback function for TIMER0 (UINTP0)
 ** Use a "normal" priority, and 64KB stack.
 */
interruptMask = (1 << 16);
result = tdrv020InterruptRegisterCallbackThread(hdl,
                                                TDRV020_PRIORITY_NORMAL,
                                                0x10000,
                                                interruptMask,
                                                callback_TIMER0,
                                                &userDataArea,
                                                &callbackHandle);

...
```

```

...
if (result != TDRV020_OK)
{
    /* handle error */
}

/*
** Initialize and start the Timer function, using register accesses.
** Refer to the FDK documentation for register description.
*/
...
/*
** Callback Function, using API Functions for Register Access
*/
void callback_TIMER0(    TDRV020_HANDLE      hdl,
                         unsigned int    interruptOccurred,
                         void          *param,
                         TDRV020_STATUSstatus)
{
    TDRV020_STATUS      result;
    USER_DATA_AREA     *pUsrData = (USER_DATA_AREA*)param;
    unsigned int        u32value;

    if (status != TDRV020_OK)
    {
        /* handle error status */
    }

    printf("[Timer 0 Interrupt]\n");

    /* Acknowledge TIMER0 interrupt source by writing to
    ** "Timer Based Interrupt Status Register" (offset may differ).
    */
    u32value = (1 << 0);
    result = tdrv020WriteBE32(hdl,
                               TDRV020_RES_MEM_1,
                               0x1002C,
                               1,
                               &u32value );

    /* handle errors */
    return;
}

```

RETURNS

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified TDRV020_HANDLE is invalid.
TDRV020_ERR_INVAL	Function or callback handle pointer is NULL.
TDRV020_ERR_TASK_CREATE	Creation of the callback thread (task) failed.

3.4.4 tdrv020InterruptUnregisterCallback

NAME

tdrv020InterruptUnregisterCallback – Unregister a User Callback Function

SYNOPSIS

```
TDRV020_STATUS tdrv020InterruptUnregisterCallback
(
    TDRV020_HANDLE     hdl
)
```

DESCRIPTION

This function unregisters a previously registered user callback thread or ISR function.

PARAMETERS

hdl

This value specifies the callback handle retrieved by a call to the corresponding register function.

EXAMPLE

```
#include <tdrv020api.h>

TDRV020_HANDLE      callbackHdl;
TDRV020_STATUS      result;

/*
 ** Unregister a callback function
 */
result = tdrv020InterruptUnregisterCallback(callbackHdl);

if (result == TDRV020_OK)
{
    /*OK */
} else {
    /* handle error */
}
```

RETURNS

On success, TDRV020_OK is returned. In the case of an error, the appropriate error code is returned by the function.

ERROR CODES

Error Code	Description
TDRV020_ERR_INVALID_HANDLE	The specified callback handle is invalid.

3.5 Endian Conversion Functions

The following conversion functions can be used to develop endian-neutral software, especially for direct access to mapped PCI resources.

3.5.1 endian_be16

NAME

endian_be16 – big-endian conversion function

SYNOPSIS

```
unsigned short endian_be16
(
    unsigned short    u16value
)
```

DESCRIPTION

This function converts a short integer value (16-bit) from the native CPU endian order to big-endian order. That means on Intel x86 architectures the value will be byte-swapped, as opposed to PowerPC architectures.

PARAMETERS

u16value

This argument specifies the data to convert

EXAMPLE

```
#include <tdrv020api.h>

unsigned short *pRawData, bigEndianData;

/* setup pRawData pointer to the correct location first */

bigEndianData = endian_be16(*pRawData);
```

RETURN VALUE

This function returns the passed value in the big-endian order.

3.5.2 endian_le16

NAME

endian_le16 – little-endian conversion function

SYNOPSIS

```
unsigned short endian_le16
(
    unsigned short    u16value
)
```

DESCRIPTION

This function converts a short integer value (16-bit) from the native CPU endian order to little-endian order. That means on PowerPC architectures the value will be byte-swapped, as opposed to Intel x86 architectures.

PARAMETERS

u16value

This argument specifies the data to convert

EXAMPLE

```
#include <tdrv020api.h>

unsigned short *pRawData, littleEndianData;

/* setup pRawData pointer to the correct location first */

littleEndianData = endian_le16(*pRawData);
```

RETURN VALUE

This function returns the passed value in the little-endian order.

3.5.3 endian_be32

NAME

endian_be32 – big-endian conversion function

SYNOPSIS

```
unsigned int endian_be32
(
    unsigned short    u32value
)
```

DESCRIPTION

This function converts an integer value (32-bit) from the native CPU endian order to big-endian order. That means on Intel x86 architectures the value will be byte-swapped, as opposed to PowerPC architectures.

PARAMETERS

u32value

This argument specifies the data to convert

EXAMPLE

```
#include <tdrv020api.h>

unsigned short *pRawData, bigEndianData;

/* setup pRawData pointer to the correct location first */

bigEndianData = endian_be32(*pRawData);
```

RETURN VALUE

This function returns the passed value in the big-endian order.

3.5.4 endian_le32

NAME

endian_le32 – little-endian conversion function

SYNOPSIS

```
unsigned short endian_le32
(
    unsigned short    u32value
)
```

DESCRIPTION

This function converts an integer value (32-bit) from the native CPU endian order to little-endian order. That means on PowerPC architectures the value will be byte-swapped, as opposed to Intel x86 architectures.

PARAMETERS

u32value

This argument specifies the data to convert

EXAMPLE

```
#include <tdrv020api.h>

unsigned short *pRawData, littleEndianData;

/* setup pRawData pointer to the correct location first */

littleEndianData = endian_le32(*pRawData);
```

RETURN VALUE

This function returns the passed value in the little-endian order.